

A closer look at your new LaunchPad Development Kit

Featured microcontroller: CC1312PSIP

This LaunchPad is great for...

- Battery-operated wireless applications operating in the Sub-1GHz ISM RF bands (868MHz and 915MHz)
- Add RF capabilities to your product using one of the supported protocols: IEEE 802.15.4g, Wi-SUN®, Wireless M-Bus, MIOTY® and proprietary protocols

What comes in the box?

LP-EM-CC1312PSIP LaunchPad

CC1312PSIP Microcontroller

- 48 MHz CPU
- 352kB Flash, 80 kB RAM
- Programmable radio supporting various protocols and up to +20 dBm at 868MHz and 915MHz
- Low power consumption

QSG
This Quick Start Guide

10-pin Debug Cable

2-wire Power Cable

- Four 32-bit or eight x 16-bit timers
- ADC with 8 channel, 12 bits and 200 ksamples/s
- DAC with 8 bits
- Serial communications: UART, SPI, I2C
- Two comparators

LP-EM-CC1312PSIP Overview

LP-EM Debug Connector
Together with a LP-XDS110 or LP-XDS110ET, allows:
- Debugging and programming
- Communicate to the host via UART
- Powering the microcontroller

10-pin Debug Connector
Allows using an external JTAG Debug Probe to debug/program the device

Button/Switch
BTN-1 (DIO15)

20-pin BoosterPack plug-in module connector
(J1, J2, J3 & J4)

CC1312PSIP Wireless Microcontroller

Button/Switch
BTN-2 (DIO14)

User LEDs
Red (DIO6)
Green (DIO7)

Antenna

Hardware setup

What do you need?

To use your new LaunchPad, you need to connect an external Debug Probe to either the 20-pin LP-EM Debug connector on the edge of the board or to the 10-pin Debug connector and supply power separately.

Option 1: Using the LP-EM Debug Connector

This is the easiest way to setup the hardware. It requires either an **LP-XDS110** or

USB to the host computer

LP-XDS110 or LP-XDS110ET

LP-EM-CC1312PSIP

Option 2: Using the 10-pin debug connector

Jumper on the position XDS110 Power

10-pin Debug Cable

2-wire Power Cable

Remove all jumpers, except GND and 3V3

USB to the host computer

Separate LaunchPad

LP-EM-CC1312PSIP

For additional details, consult dev.ti.com/LP-EM-CC1312PSIP

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATA SHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to [TI's Terms of Sale](#) or other applicable terms available either on [ti.com](https://www.ti.com) or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

TI objects to and rejects any additional or different terms you may have proposed.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2024, Texas Instruments Incorporated