

# **TPS65987x, TPS65988x Power and Data Role Swaps**

---



---



---

## **ABSTRACT**

Power and data role swaps allow individual devices to change their roles under certain conditions. This ability allows a power source to become a sink, a data DFP (Downward Facing Port) to become a data UFP (Upward Facing Port), or both. The roles are negotiated using USB Power Delivery (PD) messaging according to the USB PD specification. This application report explains the standard implementation of data and power role swaps as well as assigning data and power preferences to individual USB Type-C ports. This application report is to be used with Texas Instruments' TPS65987x and TPS65988x families of USB Type-C and USB PD controllers and associated software tools.

## **Contents**

1	Introduction .....	2
2	Role Swap Configuration in Host Interface Registers.....	2
3	Data and Power Role Swap Examples .....	3
4	Requirements for Data and Power Role Swaps .....	7
5	Verification of Data-Role and Power-Role Swaps.....	7

## **List of Figures**

1	Port Control Data Role strategy Settings in a Standard Template .....	3
2	Port Control Power Role Strategy Settings in a Standard Template .....	4
3	Port Control Register (0x29) Advanced Settings Tab for "Preferred Host" .....	4
4	Port Control Advanced Settings Tab for "preferred Source" .....	5
5	DRP Host Connected to DRP Source PD Trace (Excerpt) .....	6
6	Port Control Register "preferred_Source" .....	8
7	PD Flow With DRP Source Unpowered .....	9
8	Failed SWSr When Dead Battery flag is Set to 1 (True).....	10
9	Successful DBfg Command to Clear Dead Battery Flag.....	10
10	Verified Dead Battery flag Cleared to 0 (False) .....	11
11	Successful Swap to Source.....	11
12	SWSk Command Page Before Execution .....	12
13	SWSk Power-Role Swap to Sink Attempt (Inconclusive Result).....	13
14	PD Trace of Manual Power-Role Swap Followed by Automatic Power-Role Swap.....	14
15	"preferred Source" With <i>InitSwapToSource</i> Disabled .....	15
16	Manual Swap to Sink (Successful and Persistent) .....	15

## **List of Tables**

1	Data-Role and Power-Role Swap Requirements .....	7
---	--	---

## **Trademarks**

All trademarks are the property of their respective owners.

## 1 Introduction

The Power Delivery specification allows two connected dual-role ports to optionally switch their data role, their power role, or both roles using the power-role swap and data-role swap mechanisms.

Texas Instruments' TPS65987 and TPS65988 families of USB Type-C and USB PD controllers can be configured to automatically initiate data or power role swaps to a desired state, or the same role swaps may be initiated by an external microcontroller through host interface commands. The control configuration (0x29) register is used to specify automatically initiated role swaps. You can specify a preferred data role by using the *Initiate Swap to DFP* command instead of the *Initiate Swap to UFP* command, and can configure the device to either allow or disallow swaps through the *Process Swap to DFP* and *Process Swap to UFP* bits. The power roles have similar settings.

Using an external microcontroller to modify data and power roles using host interface commands provides an additional level of functionality. Whereas the control configuration register provides a simple preference towards one setting or the other setting, an external microcontroller can use information gathered from the TPS65987 and TPS65988 host interface status registers to make more advanced power and data role decisions. For instance, a microcontroller could use the externally powered bit of the connection partner as stored in the Rx Source Capabilities (0x30) register to make a more informed decision when setting power role orientation.

## 2 Role Swap Configuration in Host Interface Registers

The TPS65987 and TPS65988 registers include the following:

- Configuration registers:
  - 0x28, Port Configuration register, Type-C supported options fields
  - 0x29, Port control register, all fields
- Status registers:
  - 0x1A, Status register, *Port Role* and *Data Role* fields
  - 0x3F Power status register, Source or Sink field
  - 0x2D, Boot Status register, *Dead Battery* field
- Run-Time Host-Interface Commands:
  - SWSr, swap to source (power)
  - SWSk, swap to sink (power)
  - SWDF, swap to DFP (data)
  - SWUF, swap to UFP (data)

The Port Control register (0x29) is the primary register used to control role swap behavior. This register allows you to configure the initiation of role swaps, which causes the TPS65987 and TPS65988 PD controller to automatically initiate the given role swap, and it allows you to configure the processing of role swaps, which controls whether the TPS65987 and TPS65988 USB PD controller accepts or does not accept various role swap requests initiated by the port partner.

The Port Configuration register (0x28) can be used to set what initial role the device can take when Type-C connection is made. The Port Configuration field can choose between DFP only, UFP only, or DRP. The Type-C Supported Options field selects if the DRP port has additional options as Try.Src (Try Source) or Try.Snk (Try Sink), simple no options, or it can declare it is a powered accessory. The default templates that are used in this document do not have Type-C Supported options set as "No Options", but you can modify this to Try.Src for the preferred Source project.

The Status register (0x1a) reports the current data and power role of the system. The Boot Status register (0x2d) is also important as it reports whether or not the system is currently in Dead Battery Mode, and a system that is in Dead Battery Mode does not support power role swaps. Power status register (0x3f) can be used to look at power role easily.

Finally, four host interface commands can be used to manually initiate a data or power role swap using an external controller. As discussed in this application report, certain system conditions must still be met in order for a role swap to occur. If these conditions are not met, the host interface swap command is rejected.

### 3 Data and Power Role Swap Examples


The [TPS6598x Configuration Tool](#) contains multiple dual-role port configurations, all of which use one of two data and power role swap settings. Refer to the [TPS6598x Application-Customization Tool User Guide](#) to select the appropriate template that best represents your project configuration.

When a new project is started from the Configuration Tool, it asks for following questions to select correct template -


1. Which device are you using? For example, the TPS65987DDH.
2. Which template type do you want to start with?
  - Standard
  - Advanced
3. What is the port type of the design? The choices are the following:
  - Upstream Facing Port(UFP) only
  - Downstream Facing Port (DFP) only
  - Dual Role Port (DRP), prefers data host
  - Dual Role Port (DRP), prefers power source
4. Which Super Speed data controller or mux is used?

Choices on the third question determine the behavior of the Date Role and Power Role swaps. For example, if you select "DRP, prefers power source", these generated project variants initiate a power role swap if necessary to become a power source, but they do not initiate data role swap, but instead accept any data role swap. If you select "DRP, prefers power source", these variants initiate a power role swap if they start as sink, and they do not initiate data role swap, but accept data role swap.

In the second question, if you have selected the "Standard" template configuration, the Port Control (0x29) register view relating to Power and Data role swap has a simplified view each of strategy having four options. Tools generate appropriate bit settings required for the options selected, whereas in the case of the "Advanced" template configuration, the register view shows individual bits as defined in the Host Interface TRM document. [Figure 1](#) shows Port Control Data Role strategy settings in standard template and [Figure 2](#) shows Port Control Power Role strategy settings in standard template.




**Figure 1. Port Control Data Role strategy Settings in a Standard Template**



**Figure 2. Port Control Power Role Strategy Settings in a Standard Template**

Between Standard and Advanced, the only difference is the register view. This document limits discussion to Advanced template view of Port control register, as it is better suited to illustrate detailed functionality of power and data role swaps.

Note that the names of templates discussed below start with the last portion of the file name that points to the version of the Configuration tool being used, which gets updated whenever a newer version of configuration tool is used. For example, template *TPS65987DDH\_Advanced\_v5\_13.tpl* is for the TPS65987DDH device and was done based on configuration tool version 5.13.



**Figure 3. Port Control Register (0x29) Advanced Settings Tab for "Preferred Host"**

Figure 3 shows the Control Configuration register (0x29) settings for the *TPS65987DDH\_Advanced\_v5\_13.tpl* project set as "preferred Host". For this project, *Process Swap to Sink*, and *Process Swap to Source* are both enabled, but *Initiate Swap to Sink* and *Initiate Swap to Source* are both disabled. This indicates that the system accepts either power role swap request from a connected device but does not (automatically) initiate a power swap request of either type. This is an agnostic configuration since it supports both power roles without driving a preference towards one or the other.

By contrast, the data role swap settings are as follows: *Initiate Swap to DFP* and *Process Swap to DFP* are both enabled, but *Initiate Swap to UFP* and *Process Swap to UFP* are both disabled. This combination indicates that the device always attempts to become the data DFP (host) in the connection.

---


**NOTE:** The *Swap to DFP* setting indicates that the device being configured swaps to become the DFP for both the *Initiate* and *Process* settings. This setting is a preferred data configuration because it drives the system towards a configuration in which the device is data DFP if possible.

---

When setting the initiate and process bits in the Control Configuration register, avoiding a configuration that could potentially lead to an infinite sequence of data or power role swaps is important. First, system should never be configured to initiate swaps in both directions (such as selecting *Initiate Swap to UFP* and *Initiate Swap to DFP* in the same configuration). First, this would be a meaningless configuration because it provides no preference to data or power role and therefore is swapping seemingly for the sake of swapping, but second, if the port partner accepts swaps in both directions, this configuration would lead to an infinite series of swaps.

Likewise, any configuration that initiates a data or power role swap should not process swaps in the reverse direction. Two systems that are both configured to *Initiate Swap to DFP* and *Process Swap to UFP* toggle infinitely back and forth as each system continually initiates swaps to attempt to become DFP. In any event, a system that prefers to be configured as DFP would have no reason to accept swaps to UFP since this would require relinquishing the preferred role.

Comparing the settings of [Figure 3](#) to those of the "preferred Source" project as shown in [Figure 4](#), it is seen that the latter project is configured to drive towards a power source role by selecting *Process Swap to Source* and *Initiate Swap to Source*, and deselecting *Process Swap to Sink* and *Initiate Swap to Sink*. The data role is left agnostic by enabling the *Process* settings in both directions but disabling the *Initiate* settings.



**Figure 4. Port Control Advanced Settings Tab for "preferred Source"**

The following PD message trace was taken with a Teledyne LeCroy PD analyzer between two TPS65987 EVMs, one setup as the "preferred Source" and the other setup as "preferred Host". If the project which is set as "preferred Source" has the try.SRC feature enabled in port config register(0x28), the trace always follows this structure so long as either both boards are powered before connection or the board containing the source settings is powered with the host board in Dead Battery Mode. This trace was taken with both boards powered. This example also uses a non-e-marked cable, which leads to the cable resets and VConn Swap, which is discussed.

ID	Op	Port	Dir	Msg Type	Cable Plug	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	Duration	Time	Time Stamp
0				4 Packets	CBL	PD Msg	Vendor Defined	DFF or UFP	0	1					
38				38-41											
40															
41															
42	Packet	Left	SRC	DP*	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Fixed	Discover Identity	Initiator	0	PD SID
42		"Left"				Source Cap	DFF	SRC	0	3					638.442 us
43	Packet	Right	SRC	DP*	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Request	Max Cur Voltage	Dual Role	Fixed	Max Cur Voltage
43		"Right"				UFP	SNK	0	1		3.00 A	5.00 V	0		3.00 A
44	Packet	Left	SRC	DP*	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Request	Max Opr Cur/Pow	Opr Cur/Pow	Cap Mismatch	Obj Pos
44		"Left"				UFP	SNK	0	1		3.00A / 75.00W	3.00A / 75.00W	0		3
45	Packet	Left	SRC	DP*	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time	Time Stamp		
45		"Left"				Accept	DFF	SRC	1	0	501.653 us	32.019 ms	1 . 594 990 000		
46	Packet	Left	SRC	DP*	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time	Time Stamp		
46		"Left"				PS Ready	DFF	SRC	2	0	501.653 us	1.466 ms	1 . 627 009 000		
47	Packet	Right	SRC	DP*	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time	Time Stamp		
47		"Right"				DR Swap	UFP	SNK	1	0	498.256 us	1.206 ms	1 . 628 475 000		
48	Packet	Left	SRC	DP*	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time	Time Stamp		
48		"Left"				Accept	DFF	SRC	3	0	501.653 us	1.389 ms	1 . 629 681 000		
49	Packet	Left	SRC	DP*	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time	Time Stamp		
49		"Left"				Soft Reset	DFF	SRC	0	0	501.653 us	1.389 ms	1 . 629 681 000		
50	Packet	Left	SRC	DP*	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time	Time Stamp		
50		"Left"				Soft Reset	DFF	UFP	0	0	498.256 us	1.209 ms	1 . 635 963 000		
51	Packet	Right	SRC	DP*	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time	Time Stamp		
51		"Right"				VConn Swap	DFF	SNK	2	0	498.256 us	1.195 ms	1 . 637 670 000		
52	Packet	Left	SRC	DP*	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time	Time Stamp		
52		"Left"				Accept	UFP	SRC	4	0	501.653 us	2.329 ms	1 . 638 865 000		
53	Packet	Right	SRC	DP*	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time	Time Stamp		
53		"Right"				PS Ready	DFF	SNK	3	0	498.256 us	50.399 ms	1 . 641 194 000		
54	Packet	Left	SRC	DP*	CBL	Cable Reset					Duration	Idle	Time Stamp		
54		"Left"									279.972 us	155.028 us	1 . 691 593 000		
55	Packet	Left	SRC	DP*	PD Msg	Msg Type	Cable Plug	Msg ID	Obj Cnt	Duration	Idle	Time Stamp			
55		"Left"				Soft Reset	DFF	UFP	0	0	498.256 us	1.132 ms	1 . 692 028 000		
56	Packet	Left	SRC	DP*	PD Msg	Msg Type	Cable Plug	Msg ID	Obj Cnt	Duration	Idle	Time Stamp			
56		"Left"				Soft Reset	DFF	UFP	0	0	498.256 us	1.131 ms	1 . 693 658 000		
57	Packet	Left	SRC	DP*	PD Msg	Msg Type	Cable Plug	Msg ID	Obj Cnt	Duration	Idle	Time Stamp			
57		"Left"				Soft Reset	DFF	UFP	0	0	498.256 us	1.132 ms	1 . 695 287 000		
58	Packet	Left	SRC	DP*	PD Msg	Msg Type	Cable Plug	Msg ID	Obj Cnt	Duration	Idle	Time Stamp			
58		"Left"				Soft Reset	DFF	UFP	0	0	498.256 us	1.213 ms	1 . 696 917 000		
59	Packet	Left	SRC	DP*	CBL	Cable Reset				Duration	Idle	Time Stamp			
59		"Left"								279.972 us	10.243 ms	1 . 698 628 000			

Figure 5. DRP Host Connected to DRP Source PD Trace (Excerpt)

Figure 5 shows the expected sequence of PD operations for this example. This sequence is only a partial trace. The system continues with a Discover Identity, Discover SVIDs/Modes, and mode entry.

1. Packets 01 through 37 (not displayed in Figure 5) — The EVM set up as "preferred Source" connects as the DFP and "preferred Host" connects as the UFP. This always happens, so long as the EVM programmed with the source settings is powered, and try.SRC is enabled and the host settings are not.
2. Packets 38 through 41 — A Discover Identity request and three retries are sent to the cable. Because it is a non-e-marked cable, there is no response.
3. Packets 42 through 49 — The PD power contract is negotiated. See Section 3 of this document for an explanation of the configuration of this stage of PD negotiation.
4. Packet 51 — The EVM configured as "preferred Host" makes a data role swap request. This occurs because *Initiate Swap to DFP* is enabled in the Control Configuration register of this project and it is currently the UFP. Additional conditions are required for this to occur, as shown in .
5. Packet 53 — The EVM configured as "preferred Source" accepts the data role swap request. This occurs because *Process Swap to UFP* is enabled in the Control Configuration register of this project and it is currently the DFP. Additional conditions are required for this to occur, as listed in Table 1.
6. Packets 55 through 58 — The EVM configured as "preferred Host" issues a soft reset command to the cable with three retries. The new DFP always attempts a soft reset to the cable following a data-role swap to reset the message ID to 0. The cable used in this example does not respond because it is not e-marked.
7. Packet 59 — The EVM configured as "preferred Host" issues a VConn swap. The PD spec requires that a PD port must provide power to the connection cable in order to issue a cable reset. This VConn swap request is preliminary to the cable reset of packet 65.
8. Packets 61 and 63 — The VConn swap is accepted and then the EVM configured with *preferred Host*

- issues a *PS Ready* command when it is providing power to the cable.
9. Packets 65 through 70 — The host-configured port issues a *Cable Reset* command. Because the cable is not e-marked, it does not return a *Good CRC* message to this *Cable Reset* (all *Good CRC* messages have been removed from this trace to reduce its size). When no *Good CRC* message is received from the cable, the DFP (host) issues one soft reset and three retries to the cable as a result of not receiving *Good CRC* for the soft reset request. After four *Soft Reset* requests with no *Good CRC*, the port issues one final *Cable Reset* and then continues with the rest of its PD negotiation (not shown).

## 4 Requirements for Data and Power Role Swaps

A number of conditions must be met for the TPS6598x USB PD controller issues or accepts a power or data role swap. If a swap request is not issued or accepted as you expect, these conditions should be checked.


**Table 1** summarizes the requirements for each type of swap to be issued or accepted. The combination of conditions in the *Required Conditions* column must be met as specified in the table for the swap to occur. If any of the conditions in the *Blocking Conditions* column are met, the swap does not occur.

**Table 1. Data-Role and Power-Role Swap Requirements**

ACTION	TYPE	REQUIRED CONDITIONS	BLOCKING CONDITIONS
Issue swap to source	Power	Port is currently a Sink AND Initiate Swap to Source == 1 OR SWSr 4CC command issued	A previous swap-to-source request was NAK'd by the far-end PD port controller. Dead Battery flag is set in the Boot Status register (0x2D). The <i>Port Information</i> field in the System Configuration register does not support PR swap.
Accept swap to source	Power	Port is currently a Sink AND Process Swap to Source == 1	The <i>Port Information</i> field in the System Configuration register does not support PR swap. Dead Battery flag is set in Boot Status register (0x2D).
Issue swap to sink	Power	Port is currently a Source AND Initiate Swap to Sink == 1 OR SWSk 4CC command issued	A previous swap-to-sink request was NAK'd by the far-end PD port controller. The <i>Port Information</i> field in the System Configuration register does not support PR swap.
Accept swap to sink	Power	Port is currently a Source AND Process Swap to Sink == 1	The <i>Port Information</i> field in the System Configuration register does not support PR swap.
Issue swap to DFP	Data	Port is currently a UFP (Device) AND Issue Swap to DFP == 1 OR SWDF 4CC command issued	A previous swap-to-DFP request was NAK'd by the far-end PD port controller. The <i>Port Information</i> field in the System Configuration register does not support DR swap. An Alternate Mode is Active (has been entered and not exited). A Source or Sink Capabilities message has been received from port partner that does not have Dual Role Data bit set.
Accept swap to DFP	Data	Port is currently a UFP (device) AND Process Swap to DFP == 1	The <i>Port Information</i> field in the System Configuration register does not support DR. An Alternate Mode is Active (has been entered and not exited).
Issue swap to UFP	Data	Port is currently a DFP (Host) AND Initiate Swap to UFP == 1 OR SWUF 4CC command issued	A previous Swap to UFP request was NAK'd by the far-end PD port controller. The <i>Port Information</i> field in the System Configuration register does not support DR. An Alternate Mode is active (has been entered and not exited). A source or sink capabilities message has been received from port partner that does not have Dual Role Data bit set.
Accept swap to UFP	Data	Port is currently a DFP (Host) AND Process Swap to UFP == 1	The <i>Port Information</i> field in the System Configuration register does not support DR. An Alternate Mode is Active (has been entered and not exited).

## 5 Verification of Data-Role and Power-Role Swaps

The first step in verification of the data-role and power-role swaps is to verify that the settings read from the device match those that were input into the configuration tool. The relevant settings are stored in the Control Configuration register (0x29) and the System Configuration register (0x28). These settings can be modified at runtime by an external microcontroller and therefore ensuring that the settings read as expected is useful.



**Figure 6. Port Control Register "preferred\_Source"**

The settings shown in [Figure 6](#) are verified to match those of the configuration tool as shown in [Figure 4](#). Even when this is the case, you may find cases where swaps do not occur as expected. This section provides two common examples (see [Section 5.1](#) for example 1 and [Section 5.2](#) for example 2) and a walkthrough of a typical debug procedure for these scenarios using the [TPS6598x Configuration Tool](#).

### 5.1 Example 1: Debugging Power Role Swap Exiting Dead Battery Mode Operation

For the first experiment, use the two TPS65987 EVMs programmed as *preferred Source* and *preferred Host* settings from the earlier example. The *preferred Source* EVM is left unpowered, while the *preferred Host* EVM is powered.


As shown in [Figure 7](#), no power-role swap is initiated by the *preferred Source* system, even though it is a sink and has *Initiate Swap to Source* enabled.

PD	Packet	Right	SRC	50P	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Fixed	Max Cur	Voltage	Dual Role	Fixed	Max Cur	Voltage	Dual Role	Duration
32	"Right"				Source Cap DFP	DR	PR	Msg ID	0	2		3.00 A	5.00 V	1		3.00 A	12.00 V	0	765.776 us
34	"Left"			50P	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Request	Max Opr Cur/Pow	Opr Cur/Pow	Cap Mismatch	Obj Pos	Duration		
36	"Right"	SRC		50P	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time	Time Stamp						
38	"Right"	SRC		50P	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time	Time Stamp						
40	"Right"	SRC		50P	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	Duration			
42	"Left"			50P	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	ID Header		
44	"Right"	SRC		50P	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	Duration			
45	"Left"			50P	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	SVID 0	SVID 0	
46	"Right"	SRC		50P	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	Duration			
48	"Right"	SRC		50P	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	Display Port	Display Port		
50	"Left"			50P	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	DP Cap	Port Cap	
52	"Right"	SRC		50P	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	Duration			
54	"Left"			50P	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	Modes 0	Modes 0	
55-119	64 Packets		50P	CBL	PD Msg	Msg Type	Cable Plug	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	Duration	Time	
120	"Right"	SRC		50P	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	632.016 us	113.876		
122	"Left"			50P	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	Duration		
124	"Right"	SRC		50P	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	DP Status	DP Status		
126	"Left"			50P	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	DP Status	DP Status	
128	"Right"	SRC		50P	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	DP Config	DP Config		
130	"Left"			50P	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	Duration	632.016 us	
132	"Right"	SRC		50P	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	Enter Mode	Texas Instruments		
134	"Left"			50P	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	Duration	636.363 us	
136	"Right"	SRC		50P	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	SVID Specific Cmd (0x14)	Texas Instruments		
138	"Left"			50P	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	SVID Specific Cmd (0x14)	Texas Instruments	

**Figure 7. PD Flow With DRP Source Unpowered**

If the system settings have been verified, but a data-role or power-role swap is not occurring as expected, initiate the role swap manually through the [TPS6598x Configuration Tool](#).

Because the *preferred Source EVM* is not issuing the expected swap request, use debug mode on the [TPS6598x configuration tool](#) to this EVM and issue the SWSr command.




**Figure 8. Failed SWSr When Dead Battery flag is Set to 1 (True)**


Figure 8 shows the feedback from the host interface tools. The tool reports that the SWSr command was aborted. You can read Boot flags register (0x2D) to check if the Dead Battery Flag is set.

To correct this, you can power the board and then issue the DBfg command from the host interface which clears the Dead Battery flag as shown in Figure 9. Clearing of the Dead Battery flag should also be verified by reading the Boot Status register (0x2D) as shown in Figure 10.

The board must be powered before clearing the Dead Battery flag otherwise the device resets and reboots again in Dead Battery Mode operation.




**Figure 9. Successful DBfg Command to Clear Dead Battery Flag**



**Figure 10. Verified Dead Battery flag Cleared to 0 (False)**

When the Dead Battery flag has been cleared, the EVM programmed as *preferred Source* can be swapped to the power source by issuing the SWSr host interface command as shown in [Figure 11](#).




**Figure 11. Successful Swap to Source**

## 5.2 Example 2: Debugging Swap Reversal from non-Persistent Swap Conditions

Using the TPS65987 EVMs programmed as *preferred Source* and *preferred Host* settings from the earlier example, the host interface tools may be used to issue a power-role swap.

Taking the lesson learned from [Section 5.1](#), power both EVMs and then connect. The PD flow should be as was already shown in [Figure 5](#).

As a next step, use the host interface tool to issue a *Swap to Sink* PD message to the port partner.




**Figure 12. SWSk Command Page Before Execution**

[Figure 12](#) shows the command page for the SWSk (swap to sink) host interface command. The tools are attached to the EVM that have been configured with *preferred Source*, which comes up as the power source always if it has the *try.SRC* feature enabled.

Before issuing SWSk, the PD Status register, displayed at the bottom of the command page, shows that the system is currently the power source (*Source-Sink* field).

After pressing the *Execute Function* button, the tool indicates a successful execution as shown in [Figure 13](#); however, the PD Status register still indicates that the device is the power source, just as it was before issuing the SWSk command. This scenario is referred to as a *swap reversal* which is an accidental scenario that arises from configuring the TPS65987 device with non-persistent swap conditions.




**Figure 13. SWSk Power-Role Swap to Sink Attempt (Inconclusive Result)**

As shown in [Figure 13](#), the host interface tool reports a successful completion of the *Swap to Source* command, but the Power Status register reports that the device is still a source. The reason that the device is still a source after a *Swap to Sink* command that is reported as successful is shown in [Figure 14](#). This PD capture is started at the point in which the SWSk command is issued from the host interface tool. The trace shows that, in fact, a successful *Swap to Sink* PD message sequence operation does occur (packets 1 through 15); however, the system immediately issues another swap request. The reason is shown by revisiting the Port Control register on the device programmed as *preferred Source*.

ID	Packet	Left	SRC	DFT	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration		Time		Time Stamp					
											PR Swap	UFP SRC	6	0	501.683 us	1.208 ms	17 . 943 041 000			
ID	Packet	Right	DFT	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time			Time Stamp					
3	"Right"				Accept	DFF SNK	5	0	498.256 us	32.400 ms	17 . 944 249 000									
ID	Packet	Right	DFT	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time			Time Stamp					
5	"Right"				PS Ready	UFP SNK	7	0	494.949 us	2.647 ms	17 . 976 649 380									
ID	Packet	Left	SRC	DFT	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time			Time Stamp					
7	"Left"				PS Ready	DFF SRC	6	0	498.256 us	25.808 ms	17 . 979 296 000									
ID	Packet	Left	SRC	DFT	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Fixed	Max Cur	Voltage	Dual Role	Fixed	Max Cur	Voltage	Dual Role		
9	"Left"				Source Cap	DFF SRC	0	2			3.00 A	5.00 V	1		3.00 A	12.00 V	0	765.775 us	1.633 ms	
ID	Packet	Right	DFT	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Request	Max Opr Cur/Pow	Opr Cur/Pow	Cap Mismatch	Obj Pos	Duration	Time	Time		
11	"Right"				Accept	UFP SNK	0	1			3.00A / 75.00W	3.00A / 75.00W	0	1	636.363 us	1.337 ms	18 . 000 000 000			
ID	Packet	Left	SRC	DFT	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time			Time Stamp					
13	"Left"				Accept	DFF SRC	1	0	498.256 us	30.952 ms	18 . 008 074 000									
ID	Packet	Left	SRC	DFT	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time			Time Stamp					
15	"Left"				PS Ready	DFF SRC	2	0	498.256 us	1.403 ms	18 . 039 026 000									
ID	Packet	Right	DFT	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time			Time Stamp					
17	"Right"				PR Swap	UFP SNK	1	0	503.322 us	1.205 ms	18 . 040 429 000									
ID	Packet	Left	SRC	DFT	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time			Time Stamp					
19	"Left"				Accept	DFF SRC	3	0	498.256 us	31.547 ms	18 . 041 634 000									
ID	Packet	Right	DFT	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time			Time Stamp					
21	"Right"				PS Ready	DFF SNK	4	0	491.568 us	2.626 ms	18 . 073 181 344									
ID	Packet	Left	SRC	DFT	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time			Time Stamp					
23	"Left"				PS Ready	UFP SRC	2	0	501.683 us	5.394 ms	18 . 075 807 000									
ID	Packet	DFT	CBL	DFT	PD Msg	Msg Type	Cable Plug		Msg ID	Obj Cnt	Duration	Idle			Time Stamp					
25					Soft Reset	DFP or UFP	0	0	501.683 us	1.137 ms	18 . 081 201 000									
ID	Packet	DFT	CBL	DFT	PD Msg	Msg Type	Cable Plug		Msg ID	Obj Cnt	Duration	Idle			Time Stamp					
26					Soft Reset	DFP or UFP	0	0	501.683 us	1.137 ms	18 . 082 840 000									
ID	Packet	DFT	CBL	DFT	PD Msg	Msg Type	Cable Plug		Msg ID	Obj Cnt	Duration	Idle			Time Stamp					
27					Soft Reset	DFP or UFP	0	0	501.683 us	1.138 ms	18 . 084 479 000									
ID	Packet	DFT	CBL	DFT	PD Msg	Msg Type	Cable Plug		Msg ID	Obj Cnt	Duration	Idle			Time Stamp					
28					Soft Reset	DFP or UFP	0	0	501.683 us	1.274 ms	18 . 086 119 000									
ID	4 Packets	DFT	CBL	DFT	PD Msg	Msg Type	Cable Plug		Msg ID	Obj Cnt	VDM Header	Cmd	Cmd Type	Obj Pos	Vendor ID	Duration	Time	Time Stamp		
29-32					Vendor Defined	DFF or UFP	1	1			Discover Identity	Initiator	0	PD SID	638.442 us	27.812 ms	18 . 087 895 000			
ID	Packet	Left	SRC	DFT	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Fixed	Max Cur	Voltage	Dual Role	Fixed	Max Cur	Voltage	Dual Role		
33	"Left"				Source Cap	UFP SRC	0	3			3.00 A	5.00 V	0		3.00 A	12.00 V	0	3.00 A	20.00 V	0
ID	Packet	Right	DFT	SNK	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Request	Max Opr Cur/Pow	Opr Cur/Pow	Cap Mismatch	Obj Pos	Duration	Time	Time		
35	"Right"				Request	DFF SNK	0	1			3.00A / 75.00W	3.00A / 75.00W	0	3	632.016 us	1.337 ms	18 . 1			
ID	Packet	Left	SRC	DFT	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time			Time Stamp					
37	"Left"				Accept	UFP SRC	1	0	501.683 us	32.020 ms	18 . 118 846 000									
ID	Packet	Left	SRC	DFT	PD Msg	Msg Type	DR	PR	Msg ID	Obj Cnt	Duration	Time			Time Stamp					
39	"Left"				PS Ready	UFP SRC	2	0	501.683 us	18 . 150 866 000										

Figure 14. PD Trace of Manual Power-Role Swap Followed by Automatic Power-Role Swap

Referring back to Figure 6, recall that the source device has the *Initiate Swap to Source* setting enabled. The behavior of this setting is that it initiates a *Swap to Source* request at any time that the device is a sink and none of the blocking conditions of Table 1 are present. So, in this system, when the manual swap requests swaps power roles, the *Initiate Swap to Source* setting immediately swaps the power role back. In fact, any number of *Swap to Sink* requests are immediately swapped back as long as this setting is enabled.




**Figure 15. "preferred Source" With *InitSwapToSource* Disabled**

A simple means of completing this test is to use the host interface tools to disable *Initiate Swap to Sink* in the Control Configuration register (0x29) of the EVM that has been configured with *preferred Source*.

**NOTE:** Register changes made with the host interface tools are made only in the device RAM, not the system FLASH, and is therefore reset back to their default values if there is a device reset or power cycle.

Do not forget to click the *Write Register* button after making this change.

The *Process Swap to Sink* field does not need to be enabled for the SWSk command to work properly. This field is only used to evaluate swap requests that are initiated by the port partner.



**Figure 16. Manual Swap to Sink (Successful and Persistent)**

Figure 16 shows the successful completion of the SWSk host interface command after disabling *Initiate Swap to Source* field in Control Configuration register (0x29). The Power Status register now shows the device is the power sink in the connection.

## **IMPORTANT NOTICE AND DISCLAIMER**

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATA SHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to [TI's Terms of Sale](#) or other applicable terms available either on [ti.com](#) or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

TI objects to and rejects any additional or different terms you may have proposed.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265  
Copyright © 2022, Texas Instruments Incorporated