

Application Report

AM64x Power Estimation Tool



ABSTRACT

The power estimation spreadsheet provides power consumption estimates based on measured and simulated data; they are provided “as is” and are not guaranteed within a specified precision. Power consumption depends on electrical parameters, silicon process variations, environmental conditions, and use cases running on the processor during operation. Actual power consumption should be verified in the real system. This tool is meant for estimating power consumption during realistic operating modes; it is not intended for power supply sizing. This power estimation spreadsheet is preliminary and subject to change.

The spreadsheet mentioned in this document can be downloaded from [the following URL](#).

Table of Contents

1 Using the Power Estimation Tool	2
1.1 Operating Performance Point (OPP).....	2
1.2 Processor Core Utilization.....	2
1.3 LVCMOS IO.....	2
1.4 Peripherals.....	2
1.5 General.....	2
1.6 Estimated Power Consumption.....	3

Trademarks

All trademarks are the property of their respective owners.

1 Using the Power Estimation Tool

The input part of the spreadsheet consists of six sections: Operating Performance Point, Processor Core Utilization, LVCMOS IO, Peripheral, Estimated Power, and General. To use the input part the spreadsheet, users must modify the fields with their appropriate usage parameters. Cells designed for user input are in blue. Fields that cannot be modified are red. Fields in green are the output calculated power. Configure the blue cells to a value most closely aligned with your intended scenario.

The purpose of each of the four sections is:

- Operating Performance Point: Configure frequency of operation for A53s, R5s, M4, and ICSSGs.
- Processor Core Utilization: User estimated percent utilization of each core.
- LVCMOS IO: Subset of commonly used IO with selectable mode and percent utilization.
- Peripherals: Other peripherals with selectable mode and percent utilization.
- General: High level system configuration.
- Estimated Power: Power estimation output by rail. Power rails are aligned with EVM design. Selectable VDD_CORE.

1.1 Operating Performance Point (OPP)

This section allows to set the operating frequency of each of the compute cores and clusters.

- A53: 25 MHz to 1000 Mhz, depending on PLL resolution frequency step.
- R5F: 25 MHz to 800 MHz, depending on PLL resolution frequency step.
- M4F: 200 MHz or 400 MHz.
- ICSSG: 200 MHz, 225 MHz, 250 MHz, or 333 MHz.

1.2 Processor Core Utilization

This section lets you load each compute core with utilization between 0%-100% (inclusive). For guidance, 0% is an “off” or “unused” state. 1% is “idle”. 100% is maximum utilization (i.e. Dhrystone).

1.3 LVCMOS IO

This section allows you to select both Mode and Utilization of a subset of commonly used IO's on the AM64x, including UART (3.3 V), SPI (3.3 V), Ethernet (3.3 V), OSPI (1.8 V), and GPMC (3.3 V).

Note

This is not the complete set of IO's possible on the AM64x, and any IO configuration must be confirmed through the [AM64x pinmux tool](#). These are dual voltage IO domains (1.8 V or 3.3 V), but currently are fixed to match the EVM design.

- Mode: IO dependent mode and operating speed.
- Utilization (%): Specifies the utilization as a percentage of activity relative to a full load condition.

1.4 Peripherals

This section allows you to select both Mode and Utilization of the other peripherals on the AM64x. Other peripherals include DDR, High Speed IO (PCIe, USB3), USB2, SD card, eMMC, and ADC.

- Mode: Peripheral dependent operating mode.
- Utilization (%): Specifies the utilization as a percentage of activity relative to a full load condition.

1.5 General

This section lets you select junction temperature (not ambient temperature) and power estimation mode.

- Junction Temperature (°C): 0 to 105 approximate junction temperature
- Power Estimation Mode: Typ or Max ('Typ' is the typical power consumption of most devices. 'Max' is the worst-case possible due to silicon variation).

1.6 Estimated Power Consumption

The power estimation tool generates a power analysis report in this section. There is a selectable field for the two modes of operation of VDD_CORE. The report lists power supply name, voltage in Volts (V), and power consumption in Watts (W) per power rail groups. Power rail groups match the AM64x EVM design.

Note

The VDD_DDR4 estimated power is from AM64x SOC only, on the EVM this rail includes both SOC and external DDR device power. The total power consumption in Watts (W) is listed at the end of the table.

- VDD_CORE: 0.75 V or 0.85 V

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to TI's Terms of Sale (<https://www.ti.com/legal/termsofsale.html>) or other applicable terms available either on [ti.com](https://www.ti.com) or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2021, Texas Instruments Incorporated