

## **Power Line Modem with e-Meter Demonstration Platform Software Installation Guide**

The PLC (Power Line Communication) Software is a Graphical User Interface (GUI) created in Matlab® Version 6 (release 12.0).

The PLC software has been archived in a self-extracting ZIP format. To install the software, double-click the V1R2.EXE file and unzip the files to the directory C:\TI\_Platform\PLC. The following files will be copied into that directory:

- Serial port libraries (\*.dll)
- Matlab setup files (mglarchive.exe and UserSettings.mat)
- Control executables (PLC.bat and main.exe)

If you do not have Matlab® Version 6.0, you will need to install the Matlab® libraries by double clicking on the mglArchive.exe file. This will install two subdirectory trees call BIN and TOOLBOX and place the necessary Matlab® library files (DLLs) in them.

### ***Installation of USB Drivers***

The platform can either be run using a serial port or through a USB port. If operation through a USB port is desired, it is necessary to install USB drivers. If the serial port is to be used, please skip this section and proceed to “Running the PLC Software.”

To install the drivers, double-click one of the following files on the CD:

- If your operating system is Windows 98: TUSB3410\_9x.exe
- If your operating system is Windows XP, Windows 2000, or Windows NT: TUSB3410\_2K.exe

These programs will copy the proper drivers to the C:\Program Files\Texas Instruments\TI TUSB3410 Win9x Driver Installation Files Setup or C:\Program Files\Texas Instruments\TI TUSB3410 Win2K Driver Installation Files Setup directory.

Next, connect the USB cable between the computer and the Master demonstration box (the box with the SLAVE jumper not populated). Connect power to the demonstration box. Ensure that the “232” jumper on the master unit is removed to enable USB operation.

If the USB drivers have not been previously installed, the computer will display the “Found New Hardware Wizard.” When prompted for a driver, point the wizard to the directory of the driver files (by selecting the option in the wizard that allows you to specify a location of the driver files and then browse to that directory). Press “OK,” and all the files will load.

Note that the wizard may prompt for the file twice. Point the wizard to this same directory both times.

If you have already plugged in the device and Windows has determined it to be an “Other/Unknown” device, you must select the device in the Windows Device Manager (under the Unknown/Other Device Class), display the properties for the device (by double-clicking it), and then click the “Update Driver” button on the “Driver” properties tab. This will then bring up a wizard that you need to point to the directory of the driver files.

### ***Running the PLC Software***

Before running the PLC software, make sure to connect the PC serial port or USB port to the Master demonstration box (the box with the SLAVE jumper not populated) and connect power to the demonstration box. Ensure that the jumpers are set properly for either serial port or USB port operation. To run the PLC software, double-click on the PLC.bat file. This sets your PATH so that the control

software can find the Matlab® library files, changes the current directory to C:\TI\_Platform\PLC, and runs MAIN.EXE. Troubleshooting hints can be found in the “Power Line Modem with e-Meter Platform Getting Started Guide.”

## IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

<b>Products</b>		<b>Applications</b>	
Amplifiers	<a href="http://amplifier.ti.com">amplifier.ti.com</a>	Audio	<a href="http://www.ti.com/audio">www.ti.com/audio</a>
Data Converters	<a href="http://dataconverter.ti.com">dataconverter.ti.com</a>	Automotive	<a href="http://www.ti.com/automotive">www.ti.com/automotive</a>
DSP	<a href="http://dsp.ti.com">dsp.ti.com</a>	Broadband	<a href="http://www.ti.com/broadband">www.ti.com/broadband</a>
Interface	<a href="http://interface.ti.com">interface.ti.com</a>	Digital Control	<a href="http://www.ti.com/digitalcontrol">www.ti.com/digitalcontrol</a>
Logic	<a href="http://logic.ti.com">logic.ti.com</a>	Military	<a href="http://www.ti.com/military">www.ti.com/military</a>
Power Mgmt	<a href="http://power.ti.com">power.ti.com</a>	Optical Networking	<a href="http://www.ti.com/opticalnetwork">www.ti.com/opticalnetwork</a>
Microcontrollers	<a href="http://microcontroller.ti.com">microcontroller.ti.com</a>	Security	<a href="http://www.ti.com/security">www.ti.com/security</a>
		Telephony	<a href="http://www.ti.com/telephony">www.ti.com/telephony</a>
		Video & Imaging	<a href="http://www.ti.com/video">www.ti.com/video</a>
		Wireless	<a href="http://www.ti.com/wireless">www.ti.com/wireless</a>

Mailing Address: Texas Instruments  
Post Office Box 655303 Dallas, Texas 75265