

DRV89xx-Q1EVM User's Guide

This document is provided with the DRV8912-Q1EVM and DRV8908-Q1EVM customer evaluation modules (EVMs) as a supplement to the [DRV89xx-Q1 Automotive Multi-Channel H-Bridge Motor Driver data sheet](#). This user's guide details the hardware implementation of the EVM and how to install the software packages.

Contents

1	Introduction	2
	1.1 Overview	2
	1.2 Purpose and Scope	2
2	Hardware and Software Overview	3
	2.1 Hardware Connections Overview	3
	2.2 Connection Details.....	3
	2.3 LED Lights and Switch Functions	4
3	GUI Application	4
	3.1 Installation	5
4	GUI Operation	11
	4.1 Hardware Setup	11
	4.2 Launching the DRV89xx-Q1EVM GUI.....	11

List of Figures

1	DRV8912-Q1EVM shown (Actual Board May differ).....	2
2	EVM Connections (Actual Board May Differ)	4
3	Setup DRV89xx-Q1 Window	5
4	License Agreement.....	6
5	Accepted License Agreement.....	7
6	Installation Directory.....	8
7	GUI Composer Runtime	9
8	Installation Complete	10
9	Example of DRV89xx-Q1EVM GUI Open.....	11

Trademarks

All trademarks are the property of their respective owners.

1 Introduction

1.1 Overview

The DRV8912-Q1 and DRV8908-Q1 devices are integrated 4.5-V to 20-V/32-V multi-channel integrated half-bridge motor drivers which support a maximum voltage of 40-V for load-dump scenario. The DRV8912-Q1 device has 12 outputs, while the DRV8908-Q1 has 8 outputs and it also includes passive open load detection. The devices are designed to support 1-A per independent half-bridge (limited by the thermal dissipation of package) and can drive the motors in independent, sequential, or parallel mode. Also, the motor is fully controllable with forward, reverse, coasting and braking mode support. A standard 16-bit serial peripheral interface (SPI) provides a simple method for configuring the various device settings and reading fault diagnostic information through an external controller.




Figure 1. DRV8912-Q1EVM shown (Actual Board May differ)

The configuration, operation and diagnostics of the device is controlled by a 16-bit SPI with daisy chain compatibility. Internal PWM generators are also supported on this device, which allows current limiting during motor operation and can be used for the dimming control of LEDs. The device has four PWM generators which are programmable for four different PWM frequency and individual 8-bit duty control. Any half-bridge can be mapped to any internal PWM generator for realizing a parallel operation.

The device has numerous protection and diagnostic features. The open load detection feature allows for easy monitoring of the load connected to the half-bridge. The device is fully-protected from short-circuit conditions (short to OUTx, short to supply and short to ground) with OCP protection. Moreover, OTW and OTSD ensures the device thermal protection in scenario's of over-heating.

1.2 Purpose and Scope

This document is designed to be used as a startup guide and to supplement the DRV8912-Q1EVM and the DRV8908-Q1EVM. This document is intended for the engineers involved in the design, implementation, and validation of DRV89xx-Q1 devices. The scope of this document is to provide the user with a guide to evaluate the DRV89xx devices using GUI control. This document covers the hardware (HW) connections required between the DRV8912-Q1EVM and DRV8908-Q1EVM to the GUI. When the HW connections are complete, the user is required to download and open the GUI to control the connected EVM's DRV89xx-Q1 device.

2 Hardware and Software Overview



WARNING

Hot surfaces on the DRV89xx-Q1EVMs include the DRV89xx-Q1 devices (U2) and the area surrounding it.

DRV89xx-Q1EVMs is rated for power supply voltages between 4.5 VDC and 32 VDC max. It can support 1.0-A RMS Current Per Half-Bridge and total 3 A maximum current for All Outputs. Component temperatures are below the 125°C rating of the printed circuit board materia with the continuous current of all outputs be limited to total 3 A when operating for extended periods of time at an ambient temperature of 25°C. The nFAULT pin indicates when the device temperature has increased above 175°C and is approaching thermal shutdown. As with any elevated temperatures, normal precautions must be followed to avoid direct contact with the hot surface of the DRV89xx-Q1EVMs.

To minimize potential fire hazard, personal injury, or both, externally provided fans may be required to adequately cool customer-provided loads depending on loading conditions.

2.1 *Hardware Connections Overview*

The major blocks of the DRV89xx-Q1EVMs include the DRV89xx-Q1EVM, the MSP430G2553 microcontroller (MCU), the LM9036QMX-3.3/NOPB 3.3-V LDO regulator, and the USB communication. The DRV89xx-Q1EVMs are designed for an input supply from 4.5 to 32 V and 1.0-A RMS Current Per Half-Bridge and total 3 A maximum current for All Outputs.

The DRV89xx-Q1 device is used to provide the current to the motor or other load. The MCU communicates with the GUI to control the DRV89xx-Q1 device.

2.2 *Connection Details*

[Figure 1](#) shows the power connector J7 and motor phase connectors and J3 and J4. A supply voltage ranging from 4.5 V to 32 V from a battery or a DC voltage source is connected to the voltage supply pins. Each OUTx pins can be connected to a single motor winding, inductor, or latched relay coil when used in independent half-bridge mode.




Figure 2. EVM Connections (Actual Board May Differ)

2.3 LED Lights and Switch Functions

Three LED switches and one push-button switch are available on the DRV89xx-Q1EVMs to notify the user of different motor statuses and to control the operation of the motor. The STATUS LED will blink at a regular interval to provide an indication the MSP430G2553 MCU is powered and code is running. The nFAULT LED will light when the DRV89xx device detects an abnormal condition, such as overcurrent, overtemperature, or open load. The VM LED will light when a input source is connected.

The S1 switch is configured to reset the MSP430G2553 MCU. By moving the J2 jumper to the alternate position, the switch can be used as a general-purpose input if user-supplied code is installed.

3 GUI Application

The GUI is used to control the DRV89xx-Q1EVMs through USB commands. The commands are sent from the computer to the FTDI FT232RL device, which converts USB commands to UART commands. The UART commands are received by the MSP430G2553 MCU.

3.1 Installation

Follow these steps to install the GUI application:

- Step 1. Double click on the *Setup_DRV89xx-Q1EVM-y.y.y.exe* file. The y.y.y values shown may change as the GUI is updated. Reason Request
- Step 2. Click the *Next* button in the *Setup - DRV89xx-Q1* window (see [Figure 3](#)).



Figure 3. Setup DRV89xx-Q1 Window

Step 3. Review the license agreement (see [Figure 4](#)).




Figure 4. License Agreement

Step 4. Check the *I agree with the license* option if accepted and then click the *Next* button (see [Figure 5](#)).




Figure 5. Accepted License Agreement

Step 5. Select the installation directory. TI recommends using the default installation directory. Click the *Next* button when the directory is determined (see [Figure 6](#)).




Figure 6. Installation Directory

- Step 6. If you don't install GUI Composer Runtime before, please install it from website or your local hard disk (see [Figure 7](#)). Runtime v7.0.0 can be downloaded from <https://dev.ti.com/gallery/info/MotorDriversBSM/DRV89xx-Q1>. We recommend running latest version available. You may be asked to add an extension to your browser and install TI Cloud Agent. After GUI composer runtime and DRV89xx-Q1 GUI are installed, you will go step 9 and check [Figure 8](#).




Figure 7. GUI Composer Runtime

- Step 7. If you have installed "DRV89xx-Q1EVM GUI" before, please confirm you want to install this current GUI or not. Click the *Yes* button will go *Ready to Install* window.
- Step 8. Click the *Next* button in the *Ready to Install* window to begin the installation. When the installation begins, the *Installing* window shows the installation progress. The installation is now complete.

Step 9. After config "Start Menu" and "Desktop" shortcut setting, Click the *Finish* button to close the installer and begin using the GUI (see [Figure 8](#)).




Figure 8. Installation Complete

4 GUI Operation

The DRV89xx-Q1EVM GUI along with DRV89xx-Q1EVM facilitate control of brushed DC motors; LED or resistor load. The DRV89xx-Q1EVM GUI provides functionality for adjusting the speed and direction of the motor, setting various fault parameters such as voltage and current protection limits, observing the motor drive current, and monitoring the device fault status. The GUI can also be used to test the motor for best performance using various parameters available in the *Motor Control* page.

4.1 Hardware Setup

The hardware required to run the DRV89xx-Q1EVM is a micro-USB cable and a power supply from 4.5 to 32 V. Follow these steps to start up the DRV89xx-Q1EVM:

- Step 1. Connect the positive output of the DC power supply to the VM screw terminal and the negative output to the GND screw terminal.
- Step 2. Use the OUTx screw terminals to connect to the desired loads.
- Step 3. Turn on the power supply and power up the printed circuit board (PCB).
- Step 4. Connect a micro-USB cable to the DRV89xx-Q1EVM and computer.

NOTE: Steps 3 and 4 need to be followed in that order or the GUI connection will show a popup indicating a repower of EVM and reconnection of USB, in that order.

4.2 Launching the DRV89xx-Q1EVM GUI

To launch the GUI, click on the DRV89xx-Q1EVM shortcut on the desktop or navigate to the Windows Start Menu and click *All Programs*. Navigate to the Texas Instruments folder and select the DRV89xx-Q1EVM icon. If GUI "Menu" page shows "Device Disconnected", please make sure the internal net connection and USB cable connection. And then, click the button left "<>" button to restart the connection.

For a guide on the different attributes of the DRV89xx-Q1EVM GUI, refer to the [DRV89xx-Q1EVM GUI User's Guide](#). Figure 9 shows an example of the GUI.




Figure 9. Example of DRV89xx-Q1EVM GUI Open

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to TI's Terms of Sale (www.ti.com/legal/termsofsale.html) or other applicable terms available either on ti.com or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2019, Texas Instruments Incorporated