


WHILE ASSEMBLY THE LEAD MUST ALIGN ON THE EXACT CENTER OF THE PAD WIDTH.



ASSEMBLE ALL THE SMA CLOSE TO THE BOARD EDGE. THERE SHOULD NOT BE ANY GAP BETWEEN THE BOARD EDGE AND THE SMA. AMOUNT OF SOLDER APPLIED SHOULD BE UNIFORM FOR ALL THE SMA(CRITICAL).