

DPI Evaluation TPS65310-Q1

Michael Wendt

Mixed Signal Automotive-Catalog

ABSTRACT

The TPS65310A-Q1 is a power management unit, meeting the requirements of DSP controlled automotive systems (e.g. Advanced Driver Assistance Systems). With its integration of commonly used features it helps to significantly reduce board space and system costs.

The device includes one high voltage buck controller for pre-regulation combined with two buck and one boost converter for post regulation. A further integrated LDO rounds up the power supply concept and offers a flexible system design with in total five independent voltage rails. The device offers a low power state LPM0 with all rails off to reduce current consumption in case the system is constantly connected to the battery line. All outputs are protected against overload and over temperature.

An external PMOS makes the device capable of sustaining voltage transients up to 80 V (protection feature). This external PMOS can also be used in safety critical applications to protect the system in case one of the rails shows a malfunction (under-/overvoltage, over current).

Internal Soft start ensures controlled start up for all supplies. Each power supply output has adjustable output voltage based on the external resistor network settings.

The DPI (Direct Power Injection) evaluation will show the robustness of the TPS65310 device during HF Power injection at Global Pins. This test cannot replace other customer tests like BCI (Bulk Current Injection), but it gives a first indication how the device behave under HF stress.

Contents

| | | |
|----------|--|-----------|
| 1 | DPI test TPS65310 | 3 |
| 2 | DPI set up..... | 4 |
| 3 | The Test Flow | 5 |
| 4 | Equipment used for the DPI test | 6 |
| 5 | Application data | 6 |
| 6 | Nodes Stressed with DPI in Application Circuit TPS65310 | 7 |
| 7 | Observed Signal During DPI Stress | 7 |
| 8 | Test Results..... | 8 |
| 8.1 | J26, VSSENSE, CW, Load | 8 |
| 8.2 | J26, VSSENSE, AM, Load..... | 9 |
| 8.3 | J25, VIN, CW, Load..... | 10 |
| 8.4 | J25, VIN, AM, Load | 11 |
| 8.5 | J21, WAKE, CW, Load | 12 |
| 8.6 | J21, WAKE, AM, Load..... | 13 |
| 8.7 | J10, HSSENSE, CW, Load | 14 |
| 8.8 | J10, HSSENSE, AM, Load..... | 15 |
| 8.9 | J11, HSCTRL, CW, Load..... | 16 |
| 8.10 | J11, HSCTRL, AM, Load | 17 |
| 8.11 | J20, LDO, CW, Load..... | 18 |
| 8.12 | J20, LDO, AM, Load | 19 |
| 8.13 | J19, VBOOST, CW, Load | 20 |
| 8.14 | J19, VBOOST, AM, Load..... | 21 |
| 8.15 | J19, VBOOST, AM, Load..... | 22 |
| 8.16 | J22, VSUP2, CW, Load | 23 |
| 8.17 | J22, VSUP2, AM, Load..... | 24 |
| 8.18 | J24, S1_Buck, CW, Load..... | 25 |
| 8.19 | J24, S1_Buck, AM, Load | 26 |
| 8.20 | J3, VSENSE1, CW, load..... | 26 |
| 8.21 | J7, VSENSE2, CW, load..... | 26 |
| 8.22 | J5, VSENSE3, CW, load..... | 26 |
| 8.23 | J25, VIN, CW, No Load | 27 |
| 8.24 | J25, VIN, CW, Load | 28 |
| 9 | DPI Test Summary..... | 29 |

Figures

| | | |
|------------------|-------------------------|----------|
| Figure 1. | DPI Set Up | 4 |
| Figure 2. | Test Flow..... | 5 |

1 DPI test TPS65310

To ensure the EMC performance of the TPS65310, a BCI test in the real application is needed.

- The BCI (Bulk Current injection) test is difficult in an early phase of the system development since ECU is not available yet.
- Without BCI test results failures might be detected too late in the development flow.
- The DPI test is one way to detect EMC weakness of the device even if it does not ensure the pass of the BCI test.
- For the DPI test the TPS65310 is used on standard EVM at room temperature (about 25°C). The DUT (Device under Test) is soldered on the board.
- The TPS65310 was stressed with injected HF power at certain nodes and the reaction of the device will be observed. Step by step the forward power will be increased up to 30 dBm (1 W) maximum peak. This test was performed at certain frequencies.
- Certain signals are observed in digital way and analog output voltages with a multimeter or oscilloscope.
- For each first failure the HF power and the type of failure was documented.
- The same procedure will be performed for the next frequency.
- The 16 suggested frequencies are: 1 MHz, 2 MHz, 3 MHz, 5 MHZ, 8 MHz, 10 MHz, 20 MHz, 30 MHz, 50 MHz, 80 MHz, 100 MHz, 200 MHz, 300 MHz, 500 MHz, 800 MHz, 1 GHz
- DPI test signal is CW and AM 1 KHZ modulation and 80% modulation.

2 DPI set up




Figure 1. DPI Set Up

3 The Test Flow




Figure 2. Test Flow

4 Equipment used for the DPI test

- TPS65310_EMC Rev A, DPI population
- Power Supply Statron, MSPC16
- HF-Generator, Rohde & Schwarz, IMS, 9kHz-3GHz, MSPC71
- HF Amplifier, Bonn Elektronik, BLWA 0110-20, 1 MHz–1 GHz, 20 W, MSPC72
- Power Sensor, Rohde & Schwarz, NRP-Z91, MSPC72
- Multimeter Fluke 175, MSPC57, MSPC83
- Multimeter Keithley 2000, MSPC50
- MultiMate Keithley 2100, MSPC94, MSPC95
- Oscilloscope Le Croy 6100, MSPC9

5 Application data

Used board: TPS65310_EMC Rev A, DPI population. The device was stressed with standard load and with no load condition.

- Used board: TPS65310_EMC Rev A, DPI population
- V_{bat} = 13.3 V
- Buck1
 - 3.8 V
 - No load
- Buck2
 - 3.3 V, 0.45 A
 - 7.4 Ohm
- Buck3
 - 1.2 V, 0.4 A
 - 2.7 Ohm
- Boost
 - 5.0 V, 0.4 A
 - 12 Ohm
- LDO
 - 2.5 V, 0.06 A
- 40 Ohm

6 Nodes Stressed with DPI in Application Circuit TPS65310


- Global Pins
 - VSSENSE
 - VIN
 - VINPROT(not tested, decision during EMC board development)
 - WAKE
 - HSSENSE
- Local Pins
 - HSCTRL
 - LDO
 - VBOOST
 - VSUP2,3,4 = VBUCK1 connected together, only tested VSUP2 = J22
 - S1_BUCK1(S1,S2 together)
 - VMONx,VSENSEx, not testable

7 Observed Signal During DPI Stress


- BUCK1
- BUCK2
- BUCK3
- BOOST
- LDO
- SPI register failure

8 Test Results


8.1 J26, VSSENSE, CW, Load




8.2 J26, VSSENSE, AM, Load




8.3 J25, VIN, CW, Load




8.4 J25, VIN, AM, Load




8.5 J21, WAKE, CW, Load




8.6 J21, WAKE, AM, Load




8.7 J10, HSSENSE, CW, Load




8.8 J10, HSSENSE, AM, Load




8.9 J11, HSCTRL, CW, Load




8.10 J11, HSCTRL, AM, Load




8.11 J20, LDO, CW, Load




8.12 J20, LDO, AM, Load




8.13 J19, VBOOST, CW, Load




8.14 J19, VBOOST, AM, Load




8.15 J19, VBOOST, AM, Load




8.16 J22, VSUP2, CW, Load




8.17 J22, VSUP2, AM, Load

8.18 J24, S1_Buck, CW, Load



8.19 J24, S1_Buck, AM, Load



8.20 J3, VSENSE1, CW, load

By connecting the HF Amplifier to the EMC board J3, total failure observed even without HF injection.

8.21 J7, VSENSE2, CW, load


By connecting the HF Amplifier to the EMC board J3, total failure observed even without HF injection.

8.22 J5, VSENSE3, CW, load


By connecting the HF Amplifier to the EMC board J5, device was operating without HF.

By turning on the HF amplifier, the device was broken and not starting anymore.

8.23 J25, VIN, CW, No Load



8.24 J25, VIN, CW, Load



9 DPI Test Summary

- DPI Tests global pins
 - VSSENSE: Minor influence above 300 MHz down to 20 dBm
 - VIN: Minor influence at 100 MHz 28 dBm, above 300 MHz down to 22 dBm
 - WAKE: Minor influence 100 MHz AM down to 29 dBm
 - HSSENSE: No influence
 - With no load condition a difference performance was observed at VI pin at lower frequencies.
- DPI Tests local pins
 - HSCTRL: No influence
 - LDO: Major influence starting at 80 MHz down to 9 dBm @ 300 MHz, not very reproducible, since this is a local pin it might be not critical, verification on ECU level is needed (CAS BCI test).
 - VBOOST: Minor influence above 500 MHz down to 28 dBm
 - VSUPx: Minor influence above 100 MHz, down to 22 dBm
 - S1_BUCK: No influence
- DPI Tests at local pins, internal
 - VMON and VSENSE not testable due to influence of coupling network to normal operation of the application

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATA SHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to [TI's Terms of Sale](#) or other applicable terms available either on [ti.com](#) or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

TI objects to and rejects any additional or different terms you may have proposed.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2021, Texas Instruments Incorporated