

## TPSM843820 SIMPLIS Transient Model Features and Limitations

\* TPSM843820

\*\*\*\*\*

\* (C) Copyright 2020 Texas Instruments Incorporated. All rights reserved.

\*\*\*\*\*

\*\* This model is designed as an aid for customers of Texas Instruments.

\*\* TI and its licensors and suppliers make no warranties, either expressed

\*\* or implied, with respect to this model, including the warranties of

\*\* merchantability or fitness for a particular purpose. The model is

\*\* provided solely on an "as is" basis. The entire risk as to its quality

\*\* and performance is with the customer

\*\*\*\*\*

\*

\* This model is subject to change without notice. Texas Instruments

\* Incorporated is not responsible for updating this model.

\*

\*\*\*\*\*

\*

\*\* Released by: Texas Instruments Inc.

\* Part: TPSM843820

\* Date: 17NOV2023

\* Model Type: TRANSIENT,AVERAGE

\* Simulator: SIMPLIS

\* Simulator Version: 8.40h

\* EVM Order Number: TPSM843820EVM

\* EVM Users Guide: SLUUCR3 – JANUARY 2023

\* Datasheet: SLUSEU1 – JANUARY 2023

\* Topologies Supported: Buck

\*

\* Model Version: Final 1.00

\*

\*\*\*\*\*

\*

\* Updates:

\*

\* Final 1.00

\* Release to Web.

\*

\*\*\*\*\*

\*

\* Model Usage Notes:

\*

\* A. Features have been modelled

\* 1. Output Voltage Setting

\* 2. Programmable Soft-Start

\* 3. Frequency and Operation Mode Selection

\* 4. Low-side FET Zero-Crossing

- \* 5. Current Sense and Positive Overcurrent Protection(OCP)
- \* 6. Low-side FET Negative Current Limit
- \* 7. Power Good
- \* 8. Over Voltage Protection(OVP)
- \* 9. Under Voltage Protection(UVP)
- \* 10. Output Voltage Discharge
- \* 11. EN/VIN UVLO Protection
- \* 12. BOOT functionality
- \*
- \* B. Features have not been modelled
- \* 1. Operating Quiescent Current
- \* 2. Shutdown Current
- \* 3. Temperature dependent characteristics
- \* 4. Ground Pins have been tied to 0V internally and hence model does not support Inverting topologies.
- \*
- \* C. Application Notes
- \* 1. The parameter STEADY\_STATE has been used to reach the steady state faster.
- \* Keep STEADYSTATE = 0 to observe startup behaviour.
- \* Keep STEADYSTATE = 1 and appropriate IC on Inductor and capacitor to observe for faster Steady state and is must for AC Analysis.
- \*
- \*\*\*\*\*