

Application Report SLWA056-November 2008

# Understanding TRF370x Quadrature Modulator Gain Parameters

Russell Hoppenstein

HSP - Wireless Infrastructure

#### ABSTRACT

Because of the complex nature of the quadrature modulator, understanding the gain measurement can be confusing. This application report gives a detailed explanation on how the gain is measured and specified for the TRF370x quadrature modulator family.

### Introduction

Measuring the gain of a simple RF amplifier is straightforward. For a typical RF amplifier the input and output impedances are both 50 ohms. Hence, the power gain of the amplifier is measured by:

Gain [dB] = Pout [dBm] – Pin[ dBm]

This type of measurement is easy to measure with standard RF test equipment, such as a power meter and spectrum analyzer. The quadrature modulator, exemplified by the TRF370x family of devices, converts quadrature baseband signals to RF signals. This device differs from a typical RF amplifier in three ways. One, the input signals consist of two paths: I (in-phase) and Q (quadrature phase). Two, the input signals are at different frequencies compared to the output signal. Three, the input impedance at the baseband input signals is not the same as the output impedance at the RF port. This last fact dictates that measuring a power gain on the device is impractical. Instead, a voltage gain is measured and specified in the documentation.

#### **Measuring Modulator Voltage Gain**

The functional block diagram of the TRF370x modulator is shown in Figure 1. The input I/Q signals are differential. The convention used in the data sheets of TRF370x devices is to measure the input voltage as single-ended. This choice facilitates easier measuring with standard oscilloscope probes. The differential voltage is simply calculated by:

 $Vin_{differential} = 2 \times Vin_{single-ended}$ 

When measuring the voltage gain of the device, the input signals and the output signals must be expressed in the same units. The input signals are measured using an oscilloscope and are measured in volts rms. This value is converted to dBV by the standard equation:

Vin  $[dBV] = 20 \times log(Vin [Vrms])$ 

The output signal is at RF frequencies and is measured with the spectrum analyzer in power units expressed as dBm. To calculate the voltage gain, the output power must be converted first to units of volts. The conversion factor for converting the units of dBm to dBV is (see Appendix A for conversion derivation):

Vout [dBV] = Pout [dBm] - 13

Once the input signal and output signal are expressed in the same units, dBV, the voltage gain can be calculated as follows:

Voltage Gain [dB] = Vout [dBV] – Vin [dBV]

1






Figure 1. TRF370x Functional Block Diagram

#### Understanding TRF370x Data-Sheet Plots Related to Gain

Figure 1 in the data sheets of the TRF370x products shows the output power versus the input baseband single-ended voltage at one specific frequency. This figure for the TRF370317 is reproduced in Figure 2.

With a single-ended input voltage of 0.1 Vrms, the output power is approximately –3.4 dBm. The calculation for gain is as follows.

Vin [dBV] = $20 \times \log(2 \times 0.1 \text{ Vrm})$	s = -14  dBV	(1)
Vout [dBV] = -3.4 dBm - 13	= -16.4 dBV	(2)
Gain [dB] = 16.4 dBV - (-14 dBV	() = -2.4  dB	(3)

The gain of the TRF370x devices is not plotted versus frequency. Instead, output power is plotted versus frequency. For the TRF370317, the output power is measured across frequency with a constant input signal of 98 mVrms. Using Equation 1 through Equation 3, the gain can be calculated from those plots at any desired frequency.




Figure 2.



www.ti.com

## Appendix A Derivation of the dBm to dBV Conversion Factor

For a given power out (Pout) expressed in dBm, convert to the units of watts:

Pout [W] = 
$$\frac{10^{(\text{Pout [dBm]/10})}}{1000}$$
 (A-1)

Given a 50- $\Omega$  system, convert the watts to volts:

Vout [V] = 
$$\sqrt{\text{Pout [W]} \times 50} = \sqrt{\frac{10^{(\text{Pout [dBm]/10})} \times 50}{1000}}$$
 (A-2)

Next, convert volts to dBV by:

$$Vout [dBV] = 20 log(Vout [V])$$
(A-3)

Substitute and simplify the equation to yield the conversion factor:

Vout [dBV] = 
$$20 \log \sqrt{\frac{10^{(\text{Pout [dBm]/10})} \times 50}{1000}} = 10 \log \left[ 10 \left( \frac{\text{Pout [dBm]}}{10} \right) \right] + 10 \log \left( \frac{50}{1000} \right)$$
  
Vout [dBV] = Pout [dBm] - 13 (A-4)

#### **IMPORTANT NOTICE**

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

Products		Applications	
Amplifiers	amplifier.ti.com	Audio	www.ti.com/audio
Data Converters	dataconverter.ti.com	Automotive	www.ti.com/automotive
DSP	dsp.ti.com	Broadband	www.ti.com/broadband
Clocks and Timers	www.ti.com/clocks	Digital Control	www.ti.com/digitalcontrol
Interface	interface.ti.com	Medical	www.ti.com/medical
Logic	logic.ti.com	Military	www.ti.com/military
Power Mgmt	power.ti.com	Optical Networking	www.ti.com/opticalnetwork
Microcontrollers	microcontroller.ti.com	Security	www.ti.com/security
RFID	www.ti-rfid.com	Telephony	www.ti.com/telephony
RF/IF and ZigBee® Solutions	www.ti.com/lprf	Video & Imaging	www.ti.com/video
		Wireless	www.ti.com/wireless

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2008, Texas Instruments Incorporated