





IR Transmit Selection:

Jumper select IR module vs. PWM with J4
 IR module supported on some LaunchPads through the UART TX pin
 LPs that support IR module include MSP-EXP430FR1133
 LPs without dedicated IR hardware can use PWM pin for IR transmit



IR BoosterPack

TITLE: BOOST-IR

Document Number:

REV:
1.0

Date: 10/10/2014 5:09:20 PM

Sheet: 1/1