



PROC135E3 ASSEMBLY TOP



PROC135E3 ASSEMBLY BOTTOM



CARD PUSH IN
CARD PUSH LOCK
CARD PUSH OUT