Installation of LCD Kit on AM57x IDK (continued)

8 The IDK can now be powered on and used as described in the AM57x IDK Quick Start Guide that came with the IDK board.

For more information on AM57x processors, including:

- User Guide
- How Tos
- Software
- Design Files

Please visit **www.ti.com/am57x** and **www.ti.com/am57idklcd**

For support questions, please contact: **support@ti.com** or **www.ti.com/e2e**.

SPRW293A

![Texas Instruments]

AM57x IDK LCD Kit Quick Start Guide

Welcome to the AM57x IDK LCD Kit Quick Start Guide. This guide is designed to help you through the installation of the LCD screen onto an AM57x IDK. This kit enables the use of an LCD screen with the industrial development kits (IDKs) for the AM57x Cortex®-A15 and C66x processors for evaluation and testing of industrial display-focused use cases such as industrial HMI, Panel PLC, and other industrial displays. The 10.1" LCD screen has 1920×1200 resolution and supports 10-point capacitive touch. The AM57x IDK LCD Kit contains the following:

- **Hardware**
  – 10.1" LCD Screen (1920×1200)
  – LCD cable
  – Touch cable
  – Standoffs for attaching an AM57x IDK such as the TMDXIDK5728 (TMDXIDK5728 is available for purchase separately)

- **Printed documents**
  – AM57x IDK LCD Kit Quick Start Guide (this document)
 – Terms and conditions

Installation of LCD Kit on AM57x IDK

1 Make sure the AM57x IDK is powered down and unplugged from all power sources.

2 Connect the touch cable to the IDK board using connector J17 on the back side of the board. Make sure the connector is in the open position with the black portion slid outwards. Insert the plain end of the touch cable into the connector with the contacts facing away from the IDK (up). Close the connector to secure the connection.

Note: Cables should be attached in exactly the order listed here to avoid stress on connectors during installation, which can damage parts.

3 Connect the LCD cable to the LCD panel by lifting up the white flap on the connector on the LCD kit, then inserting the end of the cable into the black side of the connector with the cable contacts facing the LCD screen (down). Then push the white flap down to secure the connection.

## Installation of LCD Kit on AM57x IDK (continued)

**4** Make sure connector J16 is in the open position with the black flap raised.

5 Position the IDK board close to the LCD screen and connect the LCD cable to the IDK board using connector J16. The cable should be connected with the contacts facing away from the IDK (up). Ensure the connector is secure by pressing down on the black flap.

6 Mount the IDK on the LCD screen so that the screws on the LCD assembly fit through the holes on the PCB and attach standoffs to secure the board. Note that two standoffs must be attached if the camera module will be used. Tighten standoffs only to finger tightness; overtightening may loosen the assembly from the display frame.

Touch cable connector

Tab to be connected to the cable

7 Connect the touch cable to the LCD screen using the connector on the end of the cable. The connector is opened and closed using the black flap.

IMPORTANT NOTICE

Products		Applications	
Audio	www.ti.com/audio	Automotive and Transportation	www.ti.com/automotive
Amplifiers	amplifier.ti.com	Communications and Telecom	www.ti.com/communications
Data Converters	dataconverter.ti.com	Computers and Peripherals	www.ti.com/computers
DLP® Products	www.dlp.com	Consumer Electronics	www.ti.com/consumer-apps
DSP	dsp.ti.com	Energy and Lighting	www.ti.com/energy
Clocks and Timers	www.ti.com/clocks	Industrial	www.ti.com/industrial
Interface	interface.ti.com	Medical	www.ti.com/medical
Logic	logic.ti.com	Security	www.ti.com/security
Power Mgmt	power.ti.com	Space, Avionics and Defense	www.ti.com/space-avionics-defense
Microcontrollers	microcontroller.ti.com	Video and Imaging	www.ti.com/video
RFID	www.ti-rfid.com		
OMAP Applications Processors	www.ti.com/omap	**TI E2E Community**	e2e.ti.com
Wireless Connectivity	www.ti.com/wirelessconnectivity		