

Battery-Less Near Field Communication (NFC) Keyboard

Abstract: To be provided.

Contents

1	Hardware Block Diagram	. 2
	How to Mount the PCBA in the Keyboard	
3	How to Program the New NFC Keyboard PCBA	. 9
4	Schematic	10
5	Power Consumption Test	10
6	Android Applications	12

List of Figures

1	Hardware Block Diagram	2
2	New Keyboard—Open Box	2
3	Turn Over Keyboard	3
4	Remove Screws	4
5	Turn Keyboard Face Up	4
6	Release the Hidden Lock	5
7	Open the Cover	5
8	Remove Battery From the Keyboard	6
9	Detach the 26-Pin FPC	7
10	Attach New NFC Keyboard PCBA	8
11	Re-Mount Screws	8
12	NFC Keyboard PCBA	9
13	MSP430 USB-FET JTAG Interface	9
14	Schematic	10
15	Power Received from NFC Antenna	11
16	Power Consumed by MCU+CL330 and CL330 Itself	11
17	System Block Diagram	12
18	NfcServer	12
19	NfcKeyboard	13



Hardware Block Diagram

www.ti.com

1 Hardware Block Diagram




Figure 1. Hardware Block Diagram

- 2 How to Mount the PCBA in the Keyboard
 - 1. Open the box.



Figure 2. New Keyboard—Open Box



2. Turn the keyboard face down (see Figure 3).



Figure 3. Turn Over Keyboard



How to Mount the PCBA in the Keyboard

www.ti.com

3. Remove all of the screws (see Figure 4).



Figure 4. Remove Screws

4. Turn the keyboard face up (see Figure 5).

F														A.						1		- /-		2
esc		C	F2	Q F3	Γ	F4	E FS	Γ	Fő		,	►II F8		F9	4,	10	• FII		F12	FIS	Pr Sys	tsc srq	delete D	
、 巷	! ク 1 言	@ 2	勿 牛	# 3	Ě	\$ 4 [% 业 5 王) 6		87		* 8		(9	历 足) 0	马金		儿鄉	+=			d
tab	C. ∌		W ⊞	± Ш	E 水	« -	R ¹		· 彳 扌系	Y F	7 P 火	L U	 99	ן ג	て オ	0 人	-	P 心	ち 耳	{ [8	}] 崔	j I	
caps lock		A B		S 3 Γ≇			F 火	< ±	G ±	ア 手	H 15	す鳥	J +	X 月		ť 1	L ±		北虫) . ,	212			e ret
shift			Z T TE I		X カ 難 水	C 金	ア 鹿	V 女	T 禾	B 月	口 馬		ム 魚	M	11 85	< t		> ス ・ 舟	? /	と竹	s	hift	A page sp	
	T		olt	T	ж	Γ										€ ommar		alt option	I.	ontrol	hor		Page down	•

Figure 5. Turn Keyboard Face Up



5. Release the hidden lock in both sides by using a thin object (see Figure 6).



Figure 6. Release the Hidden Lock

6. Open the cover to see the PCBA with battery (see Figure 7)



Figure 7. Open the Cover



How to Mount the PCBA in the Keyboard

www.ti.com

7. Remove all of the screws and remove the battery from the keyboard (see Figure 8).




Figure 8. Remove Battery From the Keyboard



8. Detach the 26-pin FPC from the PCBA (see Figure 9).




Figure 9. Detach the 26-Pin FPC



How to Mount the PCBA in the Keyboard

www.ti.com

9. Attach the new NFC keyboard PCBA without the battery (see Figure 10).




Figure 10. Attach New NFC Keyboard PCBA

10. Re-mount all of the screws (see Figure 11).




Figure 11. Re-Mount Screws






Figure 12. NFC Keyboard PCBA

3.1 Spy-Bi-Wire Programming Interface

As illustrated in Figure 12, P3 in the PCBA is the 2-wire JTAG communication interface. To debug or program the onboard MSP430RF5739, you need connect all the signals on P3 to a MSP430 USB-FET. A 330- Ω resister is mounted on the PCB between the TCK and TEST pin. Note that FET will power the PCBA during the programming progress.

3.2 MSP430 USB-FET JTAG interface




Figure 13. MSP430 USB-FET JTAG Interface



Schematic

www.ti.com

4 Schematic




Figure 14. Schematic

5 Power Consumption Test

- Test based on Schematic 2.0 / PCB Rev B.
- Different mobile placement resulted different I_REGOUT but the same V_REGOUT, which may be clamped by the LDO input circuit.









Figure 15. Power Received from NFC Antenna

5.2 Current Measured on MSP430 and CL330



	I_MCU (mA)	V_MCU (v)	I_CL330 (uA)
no operation	0.85		66~70
single key stroke	0.9	3.3	
multiple keys stroke(2 ~ 5 keys)	1.0~1.4	5.5	

Figure 16. Power Consumed by MCU+CL330 and CL330 Itself

Note that MSP430RF5739 powers RF430CL330, so the current I_MCU is included in the power that CL330 consumes.



Android Applications

6 Android Applications

Figure 17 illustrates the system block diagram. This system has mobile phone and keyboard components. To operate the NFC keyboard, you need an NFC-enabled mobile phone running on Android 2.3 or later version and also the NFC batteryless keyboard. On the mobile phone, two (Android) applications need to be installed. One is NfcServer (an application that collects the key strokes via NFC communication), which is the Android side and defined as an NDEF message. After NfcServer gets the NDEF message, it will parse what is in the message (the message contains the original scan code of the key activity). Then, the scan code is handled and explained, and the character is sent to the other application, NfcKeyboard, which is an input method service in the Android system. NfcKeyboard is a simple service; the program just sends the characters and text or any control information to the other application if it uses the system edit controls.




Figure 17. System Block Diagram

6.1 NfcServer Application




Figure 18. NfcServer

This application is designed to be a helper application and can run in the background; you can hide this application by pressing the *Home/Back* button on the mobile phone or the *Hide* button in the graphical user interface (GUI). Even when the program is hidden, it still communicates with the keyboard via the NFC connection.



Limited by the Android NFC mechanism, this application may have to be called each time the NFC reader (mobile phone) and NFC device (keyboard) approaching.

In this GUI, you can see the NDEF message sent by the keyboard. The upper side of the GUI contains the characters decoded by the application, and in the lower side of the GUI, you can see the raw data contained in the NDEF message. It also maintains history information that indicates the communication errors. This function is designed for debug usage and should be eliminate in a real application.

6.2 NfcKeyboard Application

The NfcKeyboard application is an input method service application that the Android system uses for user input. You can see many of such applications implementing different language input.

You can only input Latin characters and symbols in this simple application by default. Efforts must be taken for support with other language input.

NfcKeyborad implements an input method named "NFC Keyboard" that you can find on *Language & Input* once you installed the application. In the *Language & Input* menu option, check the NFC Keyboard and also make it the default input method to enable the NfcKeyboard access. Note that when you test the keyboard with the NfcServer application, you do not need to install or change the input method as the NfcServer application handles the message by itself.

Ý 🖗 🌮 📓 🗉 🛛 🖉 🖉	12:06 👔										
📑 Language & input											
Personal dictionary											
KEYBOARD & INPUT METHODS											
Default NFC Keyboard											
Android keyboard English (US)	- <u>0</u> -										
🗹 Baidu Input	<u>-1-1-</u>										
Google voice typing	- 										
MFC Keyboard											
SPEECH											

Figure 19. NfcKeyboard

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have *not* been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

Products		Applications				
Audio	www.ti.com/audio	Automotive and Transportation	www.ti.com/automotive			
Amplifiers	amplifier.ti.com	Communications and Telecom	www.ti.com/communications			
Data Converters	dataconverter.ti.com	Computers and Peripherals	www.ti.com/computers			
DLP® Products	www.dlp.com	Consumer Electronics	www.ti.com/consumer-apps			
DSP	dsp.ti.com	Energy and Lighting	www.ti.com/energy			
Clocks and Timers	www.ti.com/clocks	Industrial	www.ti.com/industrial			
Interface	interface.ti.com	Medical	www.ti.com/medical			
Logic	logic.ti.com	Security	www.ti.com/security			
Power Mgmt	power.ti.com	Space, Avionics and Defense	www.ti.com/space-avionics-defense			
Microcontrollers	microcontroller.ti.com	Video and Imaging	www.ti.com/video			
RFID	www.ti-rfid.com					
OMAP Applications Processors	www.ti.com/omap	TI E2E Community	e2e.ti.com			
Wireless Connectivity	www.ti.com/wirelessconnectivity					

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2014, Texas Instruments Incorporated