




TEXAS INSTRUMENTS
 TSW1400 REV D
 SILKSCREEN TOP





TEXAS INSTRUMENTS
TSW1400 REV D
LAYER 1 (TOP SIDE)





TEXAS INSTRUMENTS
TSW1400 REV D
LAYER 4 (SIG2)















TEXAS INSTRUMENTS
TSW1400 REV D
LAYER 9 (SIG3)




TEXAS INSTRUMENTS
TSW1400 REV D
LAYER 10 (SIG4)







TEXAS INSTRUMENTS
TSW1400 REV D
LAYER 3 (SIG1)



TEXAS INSTRUMENTS
TSW1400 REV D
LAYER 12 (BOTTOM SIDE)