




TEXAS INSTRUMENTS
TSW38J84 EVM REV B
LAYER 2 - GND




TEXAS INSTRUMENTS
TSW38J84 EVM REV B
LAYER 3 - POWER




TEXAS INSTRUMENTS
TSW38J84 EVM REV B
LAYER 4 - GND




TEXAS INSTRUMENTS
TSW38J84 EVM REV B
LAYER 5 - GND



TEXAS INSTRUMENTS
TSW38J84 EVM REV B
LAYER 6 - POWER





TEXAS INSTRUMENTS
TSW38J84 EVM REV B
AYER 8 (BOTTOM SIDE)

