

A

B

C


D

A



B

C

D



PS0	Interface Mode	
0	4-wire, 8-bit SPI interface (SCS, SCL, SDI, SDC)	Default
1	3-wire, 9-bit SPI interface (SCS, SCL, SDI)	R9=>R8 R3=>R2



Title			BOOSTXL-K350QVG-S1 circuit diagram		
Size	Number		Revision		03
A4					
Date:	2014/12/12		Sheet of		03
File:	D:\KentecDisplay\...\BOOSTXL-K350QVG-S1.sch Doc				