

CDCLVP111-SP Total Ionizing Dose (TID) Radiation Report

High Reliability, High Performance Analog

ABSTRACT

This report discusses the results of the Total Ionizing Dose (TID) testing the Radiation Hardness Assured (RHA), QML Class V Texas Instrument’s CDCLVP111-SP (5962R1620701VXC). The RHA version of the CDCLVP111-SP passes up to 75-krad(Si) Low Dose Rate (LDR) and 100-krad(Si) High Dose Rate (HDR) TID.

NOTE: For questions or comments, contact hirelmarketing@list.ti.com.

Contents

| | | |
|---|---|---|
| 1 | Device Information..... | 2 |
| 2 | Total Dose Test Setup | 3 |
| 3 | Total Ionizing Dose (RHA) Characterization Test Results | 6 |
| 4 | Applicable and Reference Documents..... | 7 |

List of Figures

| | | |
|---|---|---|
| 1 | CDCLVP111-SP Device Used in Exposure | 3 |
| 2 | Bias Diagram Used in TID Exposure..... | 4 |
| 3 | Radiation Exposure Effect on Propagation Delay | 6 |
| 4 | Radiation Exposure Effect on Output to Output Skew..... | 6 |

List of Tables

| | | |
|---|---|---|
| 1 | Device and Exposure Details | 2 |
| 2 | HDR Biased Device and Exposure Information | 5 |
| 3 | LDR Biased Device and Exposure Information | 5 |
| 4 | LDR Unbiased Device and Exposure Information..... | 5 |

Trademarks

All trademarks are the property of their respective owners.

1 Device Information

1.1 Product Description

The CDCLVP111-SP clock driver distributes one differential clock pair of LVPECL input, (CLK0, CLK1) to ten pairs of differential LVPECL clock (Q0, Q9) outputs with minimum skew for clock distribution. The CDCLVP111-SP can accept two clock sources into an input multiplexer. The CDCLVP111-SP is specifically designed for driving 50-Ω transmission lines. When an output pin is not used, leaving it open is recommended to reduce power consumption. If only one of the output pins from a differential pair is used, the other output pin must be identically terminated to 50 Ω. The VBB reference voltage output is used if single-ended input operation is required. In this case, the VBB pin should be connected to CLK0 and bypassed to GND via a 10-nF capacitor. For high-speed performance, the differential mode is strongly recommended. The CDCLVP111-SP is characterized for operation from –55°C to 125°C. It has been RHA qualified to 75 krad(Si) under both LDR and HDR (after 540 hours of anneal).

1.2 Device Details

[Table 1](#) lists the device information used in the initial RHA TID characterization and qualification of HDR tests. Current production lot RLAT data can always be found in the Group E report shipped. The process for pulling the group E report from TI is described in the [Section 3.2](#) section.

Table 1. Device and Exposure Details

| TID HDR/LDR Details: 50 krad(Si) | |
|----------------------------------|---|
| TI Device Number | CDCLVP111-RHA (5962R1620701VXC) |
| Package | 36-Pin Ceramic Flatpack (HKG) |
| Technology | RF-SIGE |
| Die Lot Number | 5243712 |
| A/T Lot Number / Date Code | 5950799 |
| Quantity Tested | 51 units including 2 control units |
| Lot Accept/Reject | Devices passed 3 krad(Si), 10 krad(Si), 30 krad(Si) and 50 krad(Si) |
| HDR Radiation Facility | Texas Instruments SVA Group in Santa Clara, California |
| LDR Radiation Facility | RAD/Aeroflex in Colorado Springs, Colorado |
| HDR Dose Level | 3 krad(Si), 10 krad(Si), 30 krad(Si) and 50 krad(Si) |
| HDR Dose Rate | 65 rad(Si)/s |
| LDR Dose Level | 20 krad(Si), 30 krad(Si), 50 krad(Si) and 75 krad(Si) |
| LDR Dose Rate | 0.01 rad(Si)/s |
| HDR Radiation Source | Gammacell 220 Excel (GC-220E) Co-60 |
| LDR Radiation Source | Gammacell JLSA 81-24 Co-60 |
| Irradiation Temperature | Ambient, room temperature |



Figure 1. CDCLVP111-SP Device Used in Exposure

2 Total Dose Test Setup

2.1 Test Overview

The CDCLVP111-SP was tested according to MIL-STD-883, Test Method 1019.9. For this testing, Condition A and Condition D was used. For Condition A and Condition D the product was irradiated up to 75 krad(Si) the rated radiation level and then put through parametric testing on the ATE. The device was functional and passed all electrical parametric tests with the readings within (guard bands) of the Standard Microcircuit Drawing (SMD) electrical specification limits and is ELDRS free.

The CDCLVP11-SP RF-SIGE process technology contains Bipolar and CMOS components. Both HDR and LDR tests were performed.

2.2 Test Description and Facilities

The CDCLVP111-SP LDR exposure was performed on biased and unbiased devices in a Co60 gamma cell under a 10 mrad(Si)/s exposure rate. The dose rate of the irradiator used in the exposure ranges from < 10 mrad(Si)/s to a maximum of approximately 65 rad(Si)/s, determined by the distance from the source. For the LDR (10 mrad(Si)/s) exposure, the test box was positioned approximately 2 m from the source. The exposure boards are housed in a lead-aluminum box (as specified in MIL-STD-883 TM 1019.9) to harden the gamma spectrum and minimize dose enhancement effects. The irradiator calibration is maintained by Logmire Laboratories using Thermoluminescence Dosimeters (TLDs) traceable to the National Institute of Standards and Technology (NIST) and the dosimetry was verified using TLDs prior to the radiation exposures. After exposure, the devices were packed in dry ice (per MIL-STD-883 Method 1019.9 section 3.10) and returned to TI Dallas for a full post radiation electrical evaluation using Texas Instruments production Automated Test Equipment (ATE). ATE guard band test limits are set within SMD electrical limits to ensure a minimum Cpk and test error margin based on initial qualification and characterization data. Post radiation measurements were taken within 30 minutes of removal of the devices from the dry ice container. The devices were allowed to reach room temperature prior to electrical post radiation measurements.

The CDCLVP111-SP HDR exposure was performed on biased and unbiased devices in a Co60 gamma cell at TI SVA facility in Santa Clara, California. The un-attenuated dose rate of this cell is 65 rad(Si)/s. After exposure, the devices were packed in dry ice (per MIL-STD-883 Method 1019.9 section 3.10) and returned to TI Dallas for a full post radiation electrical evaluation using Texas Instruments Automated Test Equipment (ATE). ATE guard band test limits are set within SMD electrical limits to ensure a minimum Cpk and test error margin based on initial qualification and characterization data. Post radiation measurements were taken within 30 minutes of removal of the devices from the dry ice container. The devices were allowed to reach room temperature prior to electrical post radiation measurements.

2.4 Test Configuration and Condition

A step-stress (3k, 10k, 30k, 50k, 75k) test method was used to determine the TID hardness level. That is, after a predetermined TID level was reached, an electrical test was performed on a given sample of parts to verify that the units are within SMD electrical test limits. MIL-STD-883, Test Method 1019.9, Condition A, Condition D. If this passes, then the wafer lot can be certified as an RHA wafer lot.

The tables below list the samples that used during the RHA characterization.

Table 2. HDR Biased Device and Exposure Information

| HDR = 65 rad(Si)/s | | | |
|-----------------------------------|------------|------------|------------|
| Total Samples: 5 Biased/TID level | | | |
| Exposure Level: | | | |
| 3k | 10k | 30k | 75k |
| 36, 37, 38 | 39, 40, 41 | 42, 43, 44 | 45, 46, 47 |

Control Unit: 33

Table 3. LDR Biased Device and Exposure Information

| LDR = 10 mrad(Si)/s | | | |
|-----------------------------------|---------|------------|------------|
| Total Samples: 5 Biased/TID level | | | |
| Exposure Level: | | | |
| 20k | 30k | 50k | 75k |
| 1, 2, 3 | 7, 8, 9 | 13, 14, 15 | 19, 20, 21 |

Table 4. LDR Unbiased Device and Exposure Information

| LDR = 10 mrad(Si)/s | | | |
|-------------------------------------|------------|------------|------------|
| Total Samples: 5 Unbiased/TID level | | | |
| Exposure Level: | | | |
| 20k | 30k | 50k | 75k |
| 4, 5, 6 | 10, 11, 12 | 16, 17, 18 | 22, 23, 24 |

Control Unit: 42, 44

3 Total Ionizing Dose (RHA) Characterization Test Results

3.1 Total Ionizing Dose RHA Characterization Summary Results

The parametric data for the CDCLVP111-SP passes up to 75-krad(Si) LDR and HDR.

The drift of SMD electrical parameters including critical parameters through LDR is within experimental error to the drift at HDR. The device is tested to maximum total dose of 75 krad(Si) per MIL-STD-883, TM1090 Condition A, Condition D.

The CDLVP111-SP passed post electrical test over all the conditions below ensuring that the wafer lot is certifiable as 75-krad(Si) RHA. Samples were assembled from one wafer level variability regarding TID drift through post electrical test on ATE after LDR and HDR exposure.

- HDR (100 rad(Si)/s) biased: Post 3 krad(Si), 10 krad(Si), 30 krad(Si), 50 krad(Si), 75 krad(Si)
- LDR (0.01 rad(Si)/s) unbiased: Post 20 krad(Si), 30 krad(Si), 50 krad(Si), 75 krad(Si), 100 krad(Si)
- LDR (0.01 rad(Si)/s) biased: Post 20 krad(Si), 30 krad(Si), 50 krad(Si), 75 krad(Si)

Overall radiation performance was very solid. There were no functional or parametric failures at any read point. All datasheet parameters passed at all exposure levels with margin and ELDRS free. There were 2 parameters that showed a consistent trend during exposure and these were the worst case shift seen of all parameters tested. These are listed below.

1. Clk0Tpd_1000MHz:clk0Tpdlh_1000MHz@Q4

Propagation delay of the signal – exhibits a decrease from 0 krad(Si) to 20 krad(Si), but then an increase in time from 20 krad(Si) to 100 krad(Si). This amounts to a shift of ~20 ps which is < 20% of the guardbanded limit range. No failures.

2. Clk1Tskp_1000MHz:clk1Tskp@Q0

Channel to channel skew – exhibits an increase of channel skew through increased exposure.

These timing measurements can be partially attributed to slight voltage shifts seen on the output pins. The test method uses a strobe set a particular voltage to determine the output timing. If the voltage levels shift, this strobe is kept constant, this will result in a shift of the timing reading.




Figure 3. Radiation Exposure Effect on Propagation Delay




Figure 4. Radiation Exposure Effect on Output to Output Skew

3.2 Group E Full RHA Radiation Lot Acceptance (RLAT) Report

The Group E RHA RLAT summary is shipped with each TI RHA QMLV product. To see the list of all documents shipped with TI QMLV products review *Texas Instruments QML Lot Documents (SBOA140)*. This document also has instructions on how to pull the full RHA (Group E) report.

4 Applicable and Reference Documents

4.1 Applicable Documents

CDCLVP111-SP 1:10 High Speed Clock Buffer with Selectable Input Clock Driver ([SCAS946](#))

CDCLVP111-SP Evaluation Module

CDCLVP111-SP Evaluation Module User Guide ([SCAU055](#))

4.2 Reference Documents

Texas Instruments total ionizing dose radiation (total dose) test procedure follows the standards put forth in [MIL-STD-883](#) TM 1019. The document can be found at the DLA website.

IMPORTANT NOTICE FOR TI DESIGN INFORMATION AND RESOURCES

Texas Instruments Incorporated ("TI") technical, application or other design advice, services or information, including, but not limited to, reference designs and materials relating to evaluation modules, (collectively, "TI Resources") are intended to assist designers who are developing applications that incorporate TI products; by downloading, accessing or using any particular TI Resource in any way, you (individually or, if you are acting on behalf of a company, your company) agree to use it solely for this purpose and subject to the terms of this Notice.

TI's provision of TI Resources does not expand or otherwise alter TI's applicable published warranties or warranty disclaimers for TI products, and no additional obligations or liabilities arise from TI providing such TI Resources. TI reserves the right to make corrections, enhancements, improvements and other changes to its TI Resources.

You understand and agree that you remain responsible for using your independent analysis, evaluation and judgment in designing your applications and that you have full and exclusive responsibility to assure the safety of your applications and compliance of your applications (and of all TI products used in or for your applications) with all applicable regulations, laws and other applicable requirements. You represent that, with respect to your applications, you have all the necessary expertise to create and implement safeguards that (1) anticipate dangerous consequences of failures, (2) monitor failures and their consequences, and (3) lessen the likelihood of failures that might cause harm and take appropriate actions. You agree that prior to using or distributing any applications that include TI products, you will thoroughly test such applications and the functionality of such TI products as used in such applications. TI has not conducted any testing other than that specifically described in the published documentation for a particular TI Resource.

You are authorized to use, copy and modify any individual TI Resource only in connection with the development of applications that include the TI product(s) identified in such TI Resource. NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE TO ANY OTHER TI INTELLECTUAL PROPERTY RIGHT, AND NO LICENSE TO ANY TECHNOLOGY OR INTELLECTUAL PROPERTY RIGHT OF TI OR ANY THIRD PARTY IS GRANTED HEREIN, including but not limited to any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information regarding or referencing third-party products or services does not constitute a license to use such products or services, or a warranty or endorsement thereof. Use of TI Resources may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

TI RESOURCES ARE PROVIDED "AS IS" AND WITH ALL FAULTS. TI DISCLAIMS ALL OTHER WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, REGARDING TI RESOURCES OR USE THEREOF, INCLUDING BUT NOT LIMITED TO ACCURACY OR COMPLETENESS, TITLE, ANY EPIDEMIC FAILURE WARRANTY AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

TI SHALL NOT BE LIABLE FOR AND SHALL NOT DEFEND OR INDEMNIFY YOU AGAINST ANY CLAIM, INCLUDING BUT NOT LIMITED TO ANY INFRINGEMENT CLAIM THAT RELATES TO OR IS BASED ON ANY COMBINATION OF PRODUCTS EVEN IF DESCRIBED IN TI RESOURCES OR OTHERWISE. IN NO EVENT SHALL TI BE LIABLE FOR ANY ACTUAL, DIRECT, SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF TI RESOURCES OR USE THEREOF, AND REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

You agree to fully indemnify TI and its representatives against any damages, costs, losses, and/or liabilities arising out of your non-compliance with the terms and provisions of this Notice.

This Notice applies to TI Resources. Additional terms apply to the use and purchase of certain types of materials, TI products and services. These include; without limitation, TI's standard terms for semiconductor products (<http://www.ti.com/sc/docs/stdterms.htm>), [evaluation modules](#), and [samples](http://www.ti.com/sc/docs/sampterm.htm) (<http://www.ti.com/sc/docs/sampterm.htm>).

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2017, Texas Instruments Incorporated