

TI *Live!* BATTERY MANAGEMENT SYSTEMS SEMINAR

DOMINIK HARTL

DEEP DIVE INTO TI'S IMPEDANCE TRACK™
TECHNOLOGY


Agenda

- Lithium-ion (Li-ion) battery models.
- Fundamentals of gauging algorithms – Impedance Track™ technology.
- Impedance Track gauging configuration.

Li-ion battery models

Simple battery model



- A battery is a complex electrochemical system.
- A simple steady-state model can determine the full charge capacity.



$$V = OCV - I \times R_{BAT}$$



Battery impedance strongly depends on temperature

Impedance decreases about 1.5 times per 10°C increase




Battery impedance strongly depends on age

Impedance doubles after approximately 100 cycles





Chemical capacity (Q_{\max}) decreases with age



- Chemical capacity reduces by 3% to 7% after 100 cycles.
- Hence, it is very important to update Q_{\max} .

Cell-to-cell variation




- Low-frequency (1 mHz) impedance variation: can be significant 15%.
- At a 1C rate discharge, a 40-mV difference may cause a maximum state-of-charge error of $\pm 26\%$.


A Li-ion battery is a complex electrochemical system

The battery impedance spectrum corresponds to a complex impedance function $Z(s)$

Kinetic steps in Li-ion battery



Corresponding impedance spectrum




Source: Barsoukov, E., J.H. Kim, D.H. Kim, K.S. Hwang, C.O. Yoon, and H. Lee. 2000. "Parametric Analysis Using Impedance Spectroscopy: Relationship Between Material Properties and Battery Performance." Published in *Journal of New Materials for Electrochemical Systems* 3, no. 4 (October 2000): pp. 301-308.

Transient response



Capacitor C




Capacitor + resistor




Battery





Transient response



*C/3 rate current used for both tests



- Complete relaxation takes about 2,000 seconds.
- Different voltage at different instants.
- Voltage difference between 20 and 3,000 seconds is over 20 mV.





Fundamentals of gauging algorithm – Impedance Track technology

Impedance Track technology

- The Impedance Track algorithm incorporates:
 - Voltage-based gauge: accurate gauging under no load.
 - Coulomb counting: accurate gauging under load.
 - Real-time impedance updates.
 - Remaining runtime calculations.
 - State-of-health calculations.

- Uses **impedance, discharge rate** and **temperature** to calculate the usable capacity, also known as the full charge capacity.



What are the main characteristics of Impedance Track technology?

1. Chemistry table in data flash:

$$OCV = f(DOD, T); R = g(DOD, T)$$

2. Update maximum chemical capacity for each cell:


$$Q_{\max} = \frac{\text{PassedCharge}}{(\text{DOD1} - \text{DOD2})}$$

3. Impedance learning during discharge:

$$R = \frac{V - OCV}{I}$$


4. Run periodic simulations to update predictions of remaining and full charge capacity.

OCV



- Data flash contains the OCV tables.
- OCV profiles can be very consistent if the base cathode electrode chemistry is the same, such as LCO, NMC, LFP, etc.
- You can use the same OCV database with batteries produced by different manufacturers if the base chemistry is the same.

Measuring OCV and updating Q_{max}




- Passed charge is determined by Coulomb counting.
- DOD1 and DOD2 computed from the measured OCV.

$$Q_{max} = \frac{\Delta Q}{DOD2 - DOD1}$$

Measuring and updating resistance


- Data flash contains a fixed table: $R_a = f(\text{state of charge}, T)$.



- Resistance is measured in real time and R_a tables are updated:

$$R_{BAT} = \frac{OCV - V_{BAT}}{I_{AVG}}$$

Simulation to find RemCap and FCC



What are the main advantages of Impedance Track technology?

- **Dynamic learning ability**
 - Temperature variability in applications:
 - Impedance Track technology considers cell impedance changes caused by a temperature increase/decrease.
 - Impedance Track technology incorporates thermal modeling to adjust for self-heating.
 - Load variation:
 - Impedance Track technology will keep track of voltage drops caused by high load spikes.
- **Aged battery**
 - Impedance Track technology can adjust for changes in usable capacity caused by cell aging.
- **Increased run time**
 - A lower terminate voltage can be used with an Impedance Track technology-based gauge.
- **Flexibility**
 - Cell characterization.
 - Host system does not need to perform any calculations or gauging algorithms.

Impedance Track technology gauging configuration

Impedance Track gauge configuration


- The best performance from Impedance Track technology-based gauges can be obtained through the correct configuration:
 - Determine and program the correct ChemID.
 - Create relax-discharge-relax logs and use the gauging parameter calculator (GPC) GPCCHEM selection tool to identify a close match.
 - If no match, send cells to TI to characterize and create a new ChemID.
 - After programming the ChemID, perform a learning cycle (optimization cycle) to learn the R_a and Q_{max} values and finalize the golden image.

Before performing the learning cycle

- Make sure to enter the correct values for the following parameters:
 - Design capacity.
 - Design voltage.
 - Charge term taper current.
 - Discharge (Dsg) current threshold.
 - Charge (Chg) current threshold.
 - Quit current.
 - Term voltage.


Learning cycle procedure

- Discharge battery to empty.
- Relax for at least 5 hours:
 - Enable Impedance Track algorithm (0x21).
 - Update status changes from 00 to 04.
- Charge battery to full.
- Relax for at least 2 hours:
 - Q_{\max} updates at this point.
 - Update status changes to 05.
- Discharge battery to empty using rate between C/10 and C/5:
 - Resistance tables update during the discharge cycle.
- Relax for at least 5 hours:
 - Update status changes to 06.



<http://www.ti.com/lit/an/slua903/slua903.pdf>

How to improve performance for dynamic loads



- Symptom:
 - Gauge jumps to 0% when the load current suddenly increases.
- Possible causes:
 - Voltage dropped below terminate voltage with heavier current.
 - Gauge updates prediction with new heavier load and expects that “empty” will be reached immediately.

Fuel gauge configuration: Load mode

- Do **not** increase terminate voltage as a further guard band!
- If possible, lower the terminate voltage. Trust Impedance Track technology!
- **Change Load Mode and Load Select to another option.**

Load mode = 0

- Gauge will use a constant current load for simulations.

Load mode = 1

- Gauge will use a constant power load for simulations.
- Most systems use switched-mode DC/DC converters.
- As the battery voltage decreases, the current draw will increase to maintain constant power ($P = I \times V$).

Fuel gauge configuration: Load select

- **Load select** tells the gauge what load to assume for simulations.
 - If load mode = 0 (constant current):
 - 0 = Avg I Last Run
 - 1 = Present average discharge current (average over entire discharge)
 - 2 = Current
 - 3 = AverageCurrent
 - 4 = DesignCapacity/5
 - 5 = AtRate (mA)
 - 6 = User-Rate-mA
 - If load mode = 1 (constant power):
 - 0 = Avg P Last Run
 - 1 = Present average discharge power
 - 2 = Current x Voltage
 - 3 = AverageCurrent x Average Voltage (average over entire discharge)
 - 4 = DesignEnergy/5
 - 5 = AtRate (10 mW)
 - 6 = User-Rate-mW

How to improve performance at low temperatures

Symptom:

- State of charge jumps to 0% at low temperatures.



Possible causes:

- Incorrect R_bL values or thermal model parameters, or both.

Resolution:

- Perform an R_bL tweak test to get the correct R_bL and thermal model parameters using the online GPC tool.

R_bL -tweak test procedure



1. Perform charging at room temperature and let the battery relax for 2 hours.
2. Set the discharge temperature to 25°C. Wait 1 hour until pack reaches thermal equilibrium.
3. Discharge the battery at a system-typical high rate down to the minimal cell voltage. Let the battery relax for 5 hours to reach full equilibrium OCV.
4. Go to step No. 1 and repeat all steps, with the temperature set to 0°C in step No. 2.

For more details, see <http://www.ti.com/lit/ug/sluubd0/sluubd0.pdf>.

Summary

- Gauging is extremely important for extended battery run times.
- Accurate modeling of the battery, particularly the battery resistance, enables accurate prediction of the usable capacity (full charge capacity).
- Impedance Track gauges have the ability to handle a wide variety of battery operating conditions, such as varying temperature, varying loads and age.
- Correct configuration is essential in obtaining the best performance from the gauges.



Questions



© Copyright 2021 Texas Instruments Incorporated. All rights reserved.

This material is provided strictly “as-is,” for informational purposes only, and without any warranty.
Use of this material is subject to TI’s **Terms of Use**, viewable at [TI.com](https://www.ti.com)

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATA SHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to [TI's Terms of Sale](#) or other applicable terms available either on ti.com or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

TI objects to and rejects any additional or different terms you may have proposed.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2021, Texas Instruments Incorporated