

DLP2010 Light Control EVM User's Guide

Topic

Page

1	DLP2010 Light Control EVM Overview	2
2	Safety Instructions	3
3	Applicable Documents	3
4	What is in the DLP2010 Light Control EVM?	4
5	Light Engine	5
6	Quick-Start Procedure	5
7	Circuit Description	7
8	EVM Setup	8
	•	



DLP2010 Light Control EVM Overview

1 DLP2010 Light Control EVM Overview

This user's guide presents an overview of the DLP2010 Light Control evaluation module (EVM) and a general description of the main features and functions. It explains the first steps to get started, and provides a detailed description of the push buttons function, the on board LEDs, and the main connectors.



Figure 1. DLP2010 Light Control Complete EVM

2 Safety Instructions

3 Applicable Documents

The following documents are applicable to the DLP2010 Light Control EVM and are available on TI.com (www.ti.com).

- DLP2010 (0.2 WVGA) DMD data sheet (DLPS046B)
- DLPC3470 display and light controller data sheet (DLPS110)
- DLP Display and Light Control EVM GUI Tool User's Guide (DLPU074) If you need assistance, refer to the DLP and MEMS TI E2E community support forums.

4 What is in the DLP2010 Light Control EVM?

The DLP2010 Light Control module consists of three subsystems:

- Light engine: Includes the optics, red, green, and blue LEDs, and the 854 × 480 (WVGA) DMD. Capable of 25 lumens out-of-the-box.
- Driver board: Includes the DLP chipset comprising of DLPC3470 controller and DLPA2005 PMIC/LED driver. Including a header to access Trigger IN/OUT signals for camera capture and other system control
- **System board**: Includes MSP430, ITE HDMI receiver, USB-Serial bridge controller and several connectors for external inputs (HDMI, USB etc).

Figure 2. DLP2010 Light Control EVM Block Diagram

5 Light Engine

The optical engine in the EVM is developed by Asia Optics and is production ready.

The light engine consists of the following components:

- 0.2-inch WVGA DMD (DLP2010)
- OSRAM red, green, and blue LED LE BA Q6WM and LCG H9RM
- This light engine interfaces with the EVM using DMD pin mapping Option 3. Please refer to the DLPC3470 datasheet for more information about the DMD interface.

Table 1. Optical Engine Specifications

PARAMETER	MIN	ТҮР	MAX	UNIT
Brightness		25		lumens
LED Current		650		mA
Brightness Uniformity	75%			
Throw Ratio		1.65		
Offset		100%		

The dimensions of the optical engine are shown in Figure 3:

Figure 3. Dimensions of Optical Engine

6 Quick-Start Procedure

This quick-start assumes default conditions as shipped.

 Power up the DLP2010 Light Control EVM by applying an external DC power supply (19 V DC, 3.42 A) to the J10 connector. The P5V_VIN (D5) and P3P3V_SB (D6) LED will turn on to indicate that 5-V and 3.3-V standby power is applied.

External Power Supply Requirements:

- Nominal output voltage: 19 VDC
- Minimum output current: 3 A; Maximum output current: 3.42 A
- Efficiency level: VI

NOTE: TI recommends using an external power supply that complies with applicable regional safety standards such as UL, CSA, VDE, CCC, PSE, etc. A DC Power Connector 2.5mm x 5.5mm is being used on the DLP2010 Light Control EVM Main Board.

NOTE: The system is designed to operate also with an external 12-V DC power supply.

- 2. Move the SW_ONOFF switch to the ON position to turn the DLP2010 Light Control EVM on. When the DLP2010 Light Control EVM is turned on, the PROJ_ON LED D3 will turn on.
- 3. After the DLP2010 Light Control EVM is turned on; the projector will default to displaying a DLP Light Control splash image.
- 4. The focus of the image can be adjusted with the focus wheel on the optical engine.

Focus wheel

Figure 4. Optical Engine with Focus Wheel

- 5. Connect USB to the DLP2010 Light Control EVM and open the DLP Display and Light Control EVM Graphical User Interface (GUI) on your computer. If needed, connect an HDMI source to the EVM and communicate to the EVM over the GUI software.
- 6. Using the GUI, the EVM can be set into Video Display Mode or Light Control Modes. Refer to the GUI user's guide for further description. Note: Install Jumper J11 on the DLP2010 Light Control EVM Main Board to set Trigger IN/OUT voltage on the EVM. This jumper is required to gain access to the trigger signals. The jumper is not included by default.
- 7. When turning off the projector, turn off the SW_ONOFF switch prior to removing power cable. Note: To avoid potential damage to the DMD, it is recommended to turn off the projector with the SW_ONOFF before disconnecting the power.
- 8. There are ten indicator LEDs on the DLP2010 Light Control EVM, and they are defined in Table 2:

LED Reference	Signal Indication	Description
D1	HOST_IRQ	ON during DLPC3470 boot OFF when projector is running. Indicates DLPC3470 boot-up completed and ready to receive commands
D2	RESETZ	OFF when projector is turned on via SW_ONOFF
D3	PROJ_ON	On when projector is turned on via SW_ONOFF
D5	P5V_VIN	5-V power applied
D6	P3P3V_SB	Regulated 3V3 power on
D7	MSP2	ON when HDMI cable plugged in, and external video detected. OFF when external video is not detected.
D8	ACK	ON when Cypress CY3420 is I ² C master OFF when MSP430 is I ² C master
D9	REQ	ON when Cypress CY3420 requests the MSP430 to give Cypress master control of the I ² C bus
D10	GPIO1	Blinking when PC is communicating to flash over SPI
D11	GPIO0	Blinking when PC is communicating to DLPC3470 over I ² C

Table 2. LEDs on the DLP2010 Light Control EVM

7 Circuit Description

7.1 Connectors, Switch and Push Buttons on Main Board

Table 3. Installed Connectors on the Main board

INSTALLED CONNECTORS/HEADERS	DESCRIPTION
J1	MSP430 JTAG programming interface connector
J2	Header for 5-V DC power (not installed by default)
J3	Connector for audio
J4	Unsupported
J5	Header for EDID programming
J6	Connector for HDMI input
J7	Header for 5-V DC power used for fan connection
J8	Unsupported
J9	60-pin connector for DLP Light Control Display board
J10	Connector for 19-V external power supply interface
J11	Header for voltage level selection for Trigger-in/out (Install jumper to receive output signal this is not included with the EVM)
J12	Header for remaining DLPC3470 test points (not installed by default)
J13	Connector for Mini-USB cable
J14	Connector for the I ² C interface (DevaSys box) (not installed by default)

Table 4. List of Installed Push Buttons and Switch on Main Board

INSTALLED SWITCHES/PUSH BUTTONS	DESCRIPTION
SW1	Projector On/OFF Switch
PB-UP1	Source Selection First press: TPG Second press: HDMI input Third press: Splash screen
PB-SEL1	Cycle through displaying 7 curtain colors
PB-DOWN1	Flip image N/S or E/W
PB_LEFT1	Cycle 9 different TPG patterns after TPG source selected Cycle 4 different splash screens after splash source selected Change of volume when HDMI input is selected
PB_RIGHT1	Change LED current total 7 steps Change of volume when HDMI input is selected

7.2 Connectors on DLP2010 Light Control Display board

Table 5. Installed Connectors on the DLP2010 Light Control Display Board

INSTALLED SWITCHES/PUSH BUTTONS	DESCRIPTION
J1	Connector for the DMD flex cable
J2	Connector for LED cable
J3	Connector for selecting 3DR signal usage (Display or Light Control)
J4	Connector for Trigger-in and Triger-out for Light Control Application
J5	60-pin connector for DLP2010 Light Control Display board

Circuit Description

7.3 DLP2010 Light Control Trigger Description

DLPC3478 pin description	Connector J4 pin	Connector J4 pin description	Input/Output	DESCRIPTION
	5	3DR_BF	Input	For light control applications: Reserved for external trigger signal (Input). Applicable to Internal Pattern Streaming Mode only.
				Note: The 3DR pin on the DLPC3470 can be used as a 3D left or right reference indicator or as trigger input signal for light control application. A jumper on J3 has to be installed to determine the use case for this pin.
				For display application: Connect pin 1 and pin 2 of J3.
3DR				For light control application: Connect pin 2 and pin 3 of J3.
				Note: The Rev A Display Boards are using a level shifter which changes the incoming signal level to 1.8V. The correct voltage level for the DLP controller is 3.3V. If the input is not being detected correctly, following modifications are necessary:
				 Rotate R35 to disconnet pull-up resistor from 1.8V supply
				• Connect free end of R35 to 3.3V. R32 can be used which is connected to 3.3V.
TSTPT_4 ⁽²⁾	7	TSTPT_4_BF	Output	TRIG_OUT_1 signal.
GPIO_06	3	GPIO_6_BF	Output	Pattern Ready signal. Applicable to Internal Pattern Streaming Mode only.
GPIO_07	4	GPIO_7_BF	Output	TRIG_OUT_2_signal.

Table 6. DLP2010 Light Control Trigger Description ⁽¹⁾

¹⁾ Install Jumper J11 to set Trigger IN/OUT voltage on the EVM (Jumper is not included by default). For 3.3-V signal level: Connect pin 2 and p 3 of J11. For 1.8-V signal level : Connect pin 1 and pin 2 of J11.

⁽²⁾ See IMPORTATNT note below.

IMPORTANT:

The Rev A Display Boards use a level shifter which changes the incoming signal level to 1.8 V. The correct voltage level for the DLP controller is 3.3 V. If EVM does not detect the input signal correctly, modify the placement of resistors R32 and R35.

- Rotate R35 to disconnect pull-up resistor from the 1.8-V supply.
- Connect free end of R35 to 3.3 V. The 3.3-V connection at R32 can be used.

8 EVM Setup

8

The DLP2010 Light Control EVM is composed of three components:

- DLP2010 Light Control Main board
- DLP2010 Light Control Display board
- Engine with LED connection and Flex cable

The main board contains the connector for the power supply, the USB connector to communicate to the DLP2010 Light Control GUI, HDMI, audio and the connector for the DLP2010 Light Control Display board. The main board also contains the switch to turn on the projector in case the DLP2010 Light Control Display board and the engine is connected. Figure 5 shows the main connectors on the main board.

Figure 5. DLP2010 Light Control Main board

The DLP2010 Light Control Display board has three main connectors: The LED connector, the Flex cable connector, and the main board connector. The main and display board connect together via J5 and J9. Note that the main board connector J5 on the DLP2010 Light Control Display board is on the bottom, while the LED and Flex cable connectors are on the top as shown in Figure 6

Figure 6. DLP2010 Light Control Connections

The optical engine contains the DLP2010 DMD and the flash device for the DLPC3470 which will be connected via the flex cable. The LED adapter board is connecting the three LEDs with the LED connector on the DLP2010 Light Control Display board. Refer to Figure 7 to see the proper setup.

Verify that the pin numbers matches when connecting the flex cable to the DLP2010 Light Control Display board and DMD.

To ensure the LED cables are connected correctly, use the colored circles to trace each cable to the right connection. Once again, verify that the connection is as shown in Figure 7.

Figure 8 shows the final setup of all parts.

Figure 8. DLP2010 Light Control complete EVM

Ensure that everything is setup correctly before continuing. Verify that the flex cable is connected correctly to the DMD and the DLP2010 Light Control Display board.

Page

Revision History

NOTE: Page numbers for previous revisions may differ from page numbers in the current version.

Changes from A Revision (October 2018) to B Revision			Page	
•	Added pin mapping option description to Section 5		5	

Changes from Original (July 2018) to A Revision

•	Changed wording of point 6 and 1	6
•	Added Table 6 description of sensing signals on J4	7
•	Changed J10 connector description from "5-V" to "19-V" in Table 3	7
•	Added note for board modification on Rev A	8

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to TI's Terms of Sale (www.ti.com/legal/termsofsale.html) or other applicable terms available either on ti.com or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2019, Texas Instruments Incorporated