PMP20873 – 1kW Totem-Pole PFC EVM Test Report


GaN / Next Zhong Ye

Oct. 2016

Redefining the future of power through high voltage – www.TI.com/highvoltage • Complete Solutions • Robust Design Tools • Innovative Products



Start up




Note: extra 0.9 second was inserted due to DCP010512 bias long startup time.

The time can be eliminated when using bootstrap circuit.

Redefining the future of power through high voltage – www.TI.com/highvoltage • Complete Solutions • Robust Design Tools • Innovative Products



Step Load Response – High Line (230Vac)




Redefining the future of power through high voltage – www.TI.com/highvoltage

Complete Solutions
Robust Design Tools
Innovative Products




Step Load Response – High Line (230Vac)



Redefining the future of power through high voltage – www.TI.com/highvoltage • Complete Solutions • Robust Design Tools • Innovative Products



Step Load Response – Low Line (115Vac)




50 to 100% step load






Step Load Response – Low Line (115Vac)



Redefining the future of power through high voltage – www.TI.com/highvoltage • Complete Solutions • Robust Design Tools • Innovative Products


AC voltage transient Test 115V-230V at 0A load



Redefining the future of power through high voltage – www.TI.com/highvoltage • Complete Solutions • Robust Design Tools • Innovative Products




AC voltage transient Test 115V-230V at 1kW load



Redefining the future of power through high voltage – www.TI.com/highvoltage • Complete Solutions • Robust Design Tools • Innovative Products




AC frequency transient Test (45 – 66Hz @ 230V 1kW)



Redefining the future of power through high voltage – www.TI.com/highvoltage • Complete Solutions • Robust Design Tools • Innovative Products



AC drop and recovery test




Pending issues: Current software disables PFC for three AC cycles when AC drop is detected.

A large reverse current occurs at AC dropping edges.

Redefining the future of power through high voltage – www.TI.com/highvoltage • Complete Solutions • Robust Design Tools • Innovative Products




AC Current Waveforms at Full Load



Redefining the future of power through high voltage – www.TI.com/highvoltage • Complete Solutions • Robust Design Tools • Innovative Products




Efficiency



Redefining the future of power through high voltage – www.TI.com/highvoltage • Complete Solutions • Robust Design Tools • Innovative Products

🤴 Texas Instruments

Improving Power Factor by Using Higher fs




Higher switching frequency increases current loop bandwidth and improves PF.

Redefining the future of power through high voltage – www.TI.com/highvoltage • Complete Solutions • Robust Design Tools • Innovative Products

THD

Golden unit data




Inductor: 480uH

Redefining the future of power through high voltage – www.TI.com/highvoltage • Complete Solutions • Robust Design Tools • Innovative Products

🔱 Texas Instruments

Backup Slides

EMI design modification to improve efficiency



- Change CM inductor from 1.68mH to 1.2mH (DCR decreased from 30mΩ to 20mΩ by using 16 AWG 10 turn instead of 18 AWG wire)
- C103 changed from 1uF to 0.47uF
- C107 changed from 1uF to 2.2uF



IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to TI's Terms of Sale (https://www.ti.com/legal/termsofsale.html) or other applicable terms available either on ti.com or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2021, Texas Instruments Incorporated